

# INDEX

---

	Page	Page	
Air Gauge .....	20—21	Main Burner Bracket.....	25—26
Automatic Air Pump Shaft.....	22	Mud Guards—Front.....	31
Axle Front .....	2	Mud Guards—Rear.....	31
Axle Rear .....	2—4	Oil Lines to Casing.....	19
Body .....	36—37	Oil Lines to Cylinder.....	19
Body Braces .....	37—38	Oil Pump .....	18
Body Struts .....	7	Oil Valve .....	19
Brake Rod .....	7	Piping for Lamp.....	33
Brake Shaft .....	30—31	Portfolio .....	32
By Pass Valve.....	19—20	Reach Rod .....	7
Canopy Top .....	39—42	Reverse Shaft .....	22—23
Cape Top .....	38—39	Seat Covers .....	32
Car Frame .....	4—6	Starting Shaft .....	34—35
Change Gear Shaft.....	31	Steam Gauge .....	20
Condenser .....	7—8	Steam Line .....	20
Condenser Fan .....	8	Steering Arm .....	1
Dash .....	17	Steering Rod .....	17
Driving Shaft .....	35	Steering Stem .....	21
Drop Seat .....	39	Steps .....	17—18
Engine .....	8—14	Springs .....	4
Engine Shield .....	14	Sub Burner .....	26
Gasoline Line .....	24	Thermostat .....	27
Gasoline Tank .....	25	Throttle .....	21—22
Gasoline Valve .....	24—25	Tires .....	1
Generator .....	27—28	Tire Holder .....	32
Hand Air Pump.....	23—24	Tool Box .....	35
Hand Water Pump.....	23	Tools .....	35
Hood .....	14—15	Vaporizer .....	26—27
Horn .....	33—34	Victoria Top .....	42—43
Lamps .....	33	Water Lines .....	29—30
Lamp Brackets .....	32	Water Regulator .....	15
Lamp Brackets—Gas .....	32	Water Regulator Lines.....	15—16
Lower Branch .....	28	Water Tank .....	16—17
Luggage Carrier .....	34	Wheels—Front .....	1
Main Burner .....	25	Wheels—Rear .....	1

## Tires

Stock No.	No. per Car.		Plate No.	Price.
	4	Outer Casings 34x4.....	Not shown	.....
	4	Inner Tubes 34x4.....	Not shown	.....
	16	Clips .....	Not shown	.....
	16	Clip Screws .....	Not shown	.....
	4	Rim Strips .....	Not shown	.....
	2	Fingers .....	Not shown	.....
	1	Pump .....	Not shown	.....
	1	Repair Kit .....	Not shown	.....

## Steering Arm

010	F	1	Front Steering Arm R. H. Car 2806-3050 .....	1	.....
011	F	1	Front Steering Arm L. H. Car 2806-3050 .....	1	.....
012	F	2	Front Steering Arm Bearing Pins .....	1	.....
S0118	A	2	Front Steering Arm Bearing Pin Nuts .....	1	.....
088	F	2	( Front Wheel Stationary Cone Collars ) .....	1	.....
089	E	2	( Front Wheel Stationary Cones .....	1	.....
090	E	2	Front Wheel Adjusting Cones .....	1	.....
093	A	2	Front Wheel Lock Nuts .....	1	.....
094	F	2	Front Wheel Lock Washers .....	1	.....
93½	E	2	Front Wheel Felt Washers .....	1	.....
S031	F	1	Front Steering Arm Joint .....	1	.....
0099	C	2	Front Steering Arm Grease Cups .....	1	.....
0099½	C	2	Front Steering Arm Grease Cup Caps .....	1	.....
898	F	1	Front Steering Arm Joint Cover (Rear) .....	1	.....
808½	F	1	Front Steering Arm Joint Cover (Front) .....	1	.....
S0079½	E	4	Front Steering Arm Bushings .....	1	.....

## Wheels (Front)

		2	Front Wheels Complete .....	Not shown	.....
85	F	2	Front Wheel Hubs .....	1	.....
85½	F	2	Front Wheel Hub Flanges .....	1	.....
		10	Front Wheel Hub Bolts .....	1	.....
		10	Front Wheel Hub Bolt Nuts .....	1	.....
0086	F	2	Front Wheel Hub Dust Caps .....	1	.....
091	E	2	Front Wheel Hub Cups (Outer) .....	1	.....
091½	E	2	Front Wheel Hub Cups (Inner) .....	1	.....
095	F	2	Front Wheel Hub Oil Tubes .....	1	.....
095½	F	2	Front Wheel Hub Oil Tube Plates .....	Not shown	.....
0097	C	2	Front Wheel Hub Oil Tube Feed Tubes .....	1	.....
0097½	C	2	Front Wheel Hub Oil Tube Feed Tube Caps .....	1	.....
092	E	2	Front Wheel Hub Ball Retainers (Outer) .....	1	.....
092½	E	2	Front Wheel Hub Ball Retainers (Inner) .....	1	.....

## Wheels (Rear)

		2	Rear Wheels Complete .....	Not shown	.....
87	F	2	Rear Wheel Hubs .....	1	.....
87½	F	2	Rear Wheel Brake Drums .....	1	.....
		12	Rear Wheel Hub Bolts .....	1	.....
		12	Rear Wheel Hub Bolt Nuts .....	1	.....
0086	F	2	Rear Wheel Hub Dust Caps .....	1	.....

## Axle (Front)

Stock No.	No. per Car.		Plate No.	Price.
	1	Front Axle Complete .....	1	.....
3 E	2	Front Axle Spring Pads .....	1	.....
51 F	2	Front Axle Forks .....	1	.....
S03 C	2	Front Axle Dowell Pins .....	Not shown	.....
06 E	1	Front Axle Tube .....	1	.....

## Axle (Rear)

	1	Rear Axle Casing R. H. Complete .....	2	.....
	1	Rear Axle Casing L. H. Complete .....	2	.....
062 E	1	Rear Axle Casing Tube R. H. ....	2	.....
062½ F	1	Rear Axle Casing Tube L. H. ....	2	.....
47 F	2	Rear Axle Tube Ends .....	2	.....
54¾ E	2	Rear Axle Casing Tube Ends .....	2	.....
26 E	1	Rear Axle Bumper Casting R. H. ....	2	.....
26½ E	1	Rear Axle Bumper Casting L. H. ....	2	.....
26¾ E	2	Rear Axle Bumper Rubber .....	2	.....
S017 E	3	Rear Axle Tube End Dowell Pins .....	Not shown	.....
70 E	2	Rear Axle Spring Pads .....	2	.....
70½ E	2	Rear Axle Spring Pad Caps .....	2	.....
S070 F	4	Rear Axle Spring Pad Studs .....	2	.....
S036 E	4	Rear Axle Spring Pad Stud Nuts .....	2	.....
0127½ C	4	Rear Axle Spring Pad Lock Washers .....	2	.....
0000 C	2	Rear Axle Spring Pad Grease Cups .....	2	.....
0009½ C	2	Rear Axle Spring Pad Grease Cup Caps .....	2	.....
0000 C	2	Rear Axle Cone Grease Cups .....	2	.....
0000½ C	2	Rear Axle Cone Grease Cup Caps .....	2	.....
54 F	1	Rear Axle Gear Case R. H. ....	2	.....
54½ F	1	Rear Axle Gear Case L. H. ....	2	.....
S016 C	11	Rear Axle Gear Case Bolts .....	2	.....
S054¾ E	16	Rear Axle Tube End Bolts .....	2	.....
S055 C	13	Rear Axle Gear Case Bolt Nuts .....	2	.....
054¾ E	16	Rear Axle Tube End Bolt Washers .....	2	.....
063 E	2	Rear Axle Tube End Dust Caps .....	2	.....
056½ E	1	Rear Axle Tie Rod .....	2	.....
S0118 A	4	Rear Axle Tie Rod Nuts .....	2	.....
054¾ E	4	Rear Axle Tie Rod Washers .....	2	.....
S51 C	2	Rear Axle Casing Filling Plugs ¼" .....	2	.....
S054 F	2	Reach Bracket Clamp Bolts .....	2	.....
S055 C	2	Reach Bracket Clamp Bolt Nuts .....	2	.....
90 E	1	Rear Axle Spring Pad Collar .....	2	.....
061 F	1	Rear Axle R. H. (26-7½") .....	2	.....
061½ F	1	Rear Axle L. H. (34-5½") .....	2	.....
058 C	2	Rear Axle Compensating Gears .....	2	.....
060 C	3	Rear Axle Compensating Gear Pinions .....	2	.....
S060 C	3	Rear Axle Compensating Gear Pinion Studs .....	2	.....
S058 C	6	Rear Axle Compensating Gear Lock Screws .....	2	.....
56 E	1	Rear Axle Compensating Gear Housing .....	2	.....
57 E	1	Rear Axle Compensating Gear Housing Cover .....	2	.....
S057 E	4	Rear Axle Compensating Gear Housing Bolts .....	2	.....

## Axle (Rear)—Continued

3

Stock No.	No. per Car.		Plate No.	Price.
S057½ F	2	Rear Axle Compensating Gear Housing Rivets ..	2	.....
062½ C	1	Rear Axle Separator .....	2	.....
061½ C	1	Rear Axle Separator Collar .....	2	.....
055 F	1	Rear Axle Driving Gear .....	2	.....
066 F	1	Rear Axle Driving Gear Pinion .....	2	.....
0175 E	1	Rear Axle Change Gear Quill Gear .....	2	.....
0176 E	1	Rear Axle Change Gear Sliding Gear .....	2	.....
00177½ E	1	Rear Axle Change Gear Shaft Bushing .....	2	.....
0171 E	1	Rear Axle Change Gear Roller Bearing .....	2	.....
0170 E	1	Rear Axle Change Gear Roller Bearing Shaft ..	2	.....
0170¼ E	1	Rear Axle Change Gear Roller Bearing Collar ..	2	.....
057½ E	2	Rear Axle Driving Gear Cones .....	2	.....
059 E	2	Rear Axle Driving Gear Adjusting Cups .....	2	.....
059¼ E	1	Rear Axle Driving Gear Adjusting Cup Lock Pin (Short) .....	2	.....
060¼ E	1	Rear Axle Driving Gear Adjusting Cup Lock Pin (Long) .....	2	.....
059½ E	2	Rear Axle Adjusting Cup Ball Retainers .....	2	.....
S059 E	2	Rear Axle Driving Gear Adjusting Cup Rings ..	2	.....
065 E	1	Rear Axle Driving Pinion Shaft .....	2	.....
S076½ E	1	Rear Axle Driving Pinion Shaft Washers .....	3	.....
067½ E	1	Rear Axle Driving Pinion Adj. Cone .....	3	.....
083 E	1	Rear Axle Driving Pinion Cone (Inner) .....	3	.....
080 E	1	Rear Axle Driving Pinion Ball Cup .....	3	.....
092½ E	1	Rear Axle Driving Pinion Ball Cup Retainer ..	3	.....
067 E	1	Rear Axle Driving Pinion Adj. Ball Cup .....	3	.....
067¼ E	1	Rear Axle Driving Pinion Adj. Ball Clip .....	3	.....
0065¼ E	1	Rear Axle Driving Pinion Oil Tube .....	3	.....
65½ E	1	Rear Axle Driving Pinion Felt Washer .....	3	.....
068 F	1	Rear Axle Driving Pinion Toggle .....	3	.....
S068 F	1	Rear Axle Driving Pinion Toggle Pin (Small) ..	3	.....
S071 F	1	Rear Axle Driving Pinion Toggle Pin (Large) ..	3	.....
071½ F	1	Rear Axle Driving Pinion Toggle Center .....	3	.....
S013 C	2	Rear Axle Driving Pinion Toggle Bolts ⅜" .....	3	.....
S013 F	2	Rear Axle Driving Pinion Toggle Bolts ⅜" .....	3	.....
S036½ E	2	Rear Axle Driving Pinion Toggle Bolt Nuts ⅜" ..	3	.....
S068½ F	2	Rear Axle Driving Shaft Toggle Dust Caps .....	3	.....
	4	Rear Axle Driving Shaft Toggle Dust Cap Screws .....	Not shown	.....
S055 C	2	Rear Axle Driving Pinion Toggle Bolt Nuts ⅜" ..	3	.....
065¾ E	1	Rear Axle Driving Pinion Check Spring .....	3	.....
	2	Rear Axle Driving Pinion Check Balls .....	Not shown	.....
S0079 E	2	Rear Axle Slide Gear Shifter Blocks .....	3	.....
40½ F	1	Rear Axle Slide Gear Shifter Lever .....	3	.....
S0129 D	1	Rear Axle Slide Gear Shifter Lever Wedge Pins ..	3	.....
S081 A	1	Rear Axle Slide Gear Shifter Lever Wedge Pin Nut .....	3	.....
079 E	1	Rear Axle Slide Gear Shifter .....	3	.....

## Axle (Rear)—Continued

Stock No.	No. per Car.		Plate No.	Price.
S0079¼ E	1	Rear Axle Slide Gear Shifter Bearing Tube.....	3	.....
061¼ E	2	Rear Axle Thrust Washers .....	3	.....
059¼ E	2	Rear Axle Shimming Washers .....	3	.....
048 F	2	Rear Axle Cones .....	3	.....
049 E	2	Rear Axle Cone Bearings .....	3	.....
063½ E	2	Rear Axle Tube End Ball Washer Retainers.....	3	.....
48½ E	2	Rear Axle Cone Felt Washers.....	3	.....
064 E	2	Rear Axle Nuts .....	3	.....
076 F	1	Rear Axle Brake Wing R. H. ....	3	.....
076¼ F	1	Rear Axle Brake Wing L. H. ....	3	.....
40 G	2	Rear Axle Brake Wing Levers .....	3	.....
S0129 F	2	Rear Axle Brake Wing Lever Wedge Pins .....	3	.....
S055 C	2	Rear Axle Brake Wing Lever Wedge Pin Nuts.	3	.....
S075¼ E	2	Rear Axle Brake Wing Centering Pins .....	3	.....
S075½ E	2	Rear Axle Brake Wing Centering Pin Tube Pins	3	.....
0047½ F	2	Rear Axle Brake Wing Tubes .....	3	.....
040¼ F	2	Rear Axle Brake Wing Lever Washers .....	3	.....
0075¼ FF	2	Rear Axle Brake Rings .....	3	.....
S075 F	2	Rear Axle Brake Ring Adj. Screws .....	3	.....
S075¼ F	2	Rear Axle Brake Ring Spring Pins .....	3	.....
075¼ F	2	Rear Axle Brake Ring Springs .....	3	.....
S0075¼ FF	1	Rear Axle Brake Ring Lock Screws R. H.....	3	.....
S0075¼ FF	1	Rear Axle Brake Ring Lock Screws L. H.....	3	.....

## Springs

05 F	2	Front Springs (40x1¼—6 leaf) .....	1	.....
034 F	2	Rear Springs (44¼x1¼—7 leaf) .....	1	.....
034¼ F	4	Rear Springs Cge. Clips .....	1	.....
05½ F	4	Front Springs Cge. Clips .....	1	.....
034¼ E	8	Spring Leaf Clips .....	3	.....
S034¼ E	8	Spring Leaf Clip Rivets .....	3	.....
S034¼ E	8	Spring Leaf Clip Washers .....	3	.....
46 F	6	Spring Yokes .....	3	.....
46 FF	2	Spring Yokes .....	3	.....
S046 F	14	Spring Yoke Bolts .....	3	.....
S036½ E	14	Spring Yoke Bolt Nuts .....	3	.....
S034 E	16	Spring Clip Nuts .....	3	.....
S08 F	4	Spring Dowell Pins .....	1	.....
S081 A	4	Spring Dowell Pin Nuts .....	3	.....
4 E	2	Front Spring Shims .....	1	.....
4 E	2	Rear Spring Shims .....	1	.....

## Car Frame

266 F	1	Wooden Frame .....	Not shown	.....
0260 F	2	Rocker Plates .....	Not shown	.....
0260¼ E	2	Frame Braces Center—Under Water Tank .....	4	.....
0260½ E	2	Frame Braces Front .....	4	.....
0260¾ E	2	Frame Braces Rear .....	Not shown	.....

## Car Frame—Continued

Stock No.	No. per Car.		Plate No.	Price.
8 F	1	Front Spring Horn R. H. ....	4	.....
9 F	1	Front Spring Horn L. H. ....	4	.....
43 E	1	Rear Spring Horn R. H. ....	4	.....
44 E	1	Rear Spring Horn L. H. ....	4	.....
45 F	2	Front Body Loops ....	4	.....
45½ F	1	Rear Body Loops R. H. ....	4	.....
45¾ F	1	Rear Body Loops L. H. ....	4	.....
0261 E	1	Engine Support No. 1 R. H. ....	4	.....
0263 E	1	Engine Support No. 3 L. H. ....	4	.....
0262 E	1	Cross Support No. 2 Front ....	4	.....
0264 F	1	Cross Support Center ....	4	.....
0265 F	1	Cross Support Rear ....	4	.....
00214 E	3	Air Pump Shaft Brackets ....	4	.....
195 E	1	Gasoline Tank Front Bracket ....	5	.....
196 E	1	Gasoline Tank Front Bracket Cap ....	5	.....
220 E	1	Gasoline Tank Rear Bracket ....	5	.....
221 E	1	Gasoline Tank Rear Bracket Cap ....	5	.....
S220 C	2	Gasoline Tank Rear Bracket Cap Bolts ....	5	.....
37 F	1	Foot Brake Wing Lever Bracket ....	5	.....
S0037 E	2	Foot Brake Wing Lever Bracket Bushings ....	5	.....
037½ E	2	Foot Brake Wing Lever Bracket Shims ....	5	.....
210 C	1	Hand Air and Water Pump Bracket ....	4	.....
027 F	1	Reach Rod Bracket ....	5	.....
39 F	1	Brake Shaft Bracket ....	5	.....
S0039 F	1	Brake Shaft Bracket Bushing ....	5	.....
39½ F	1	Brake and Reverse Shaft Bracket ....	5	.....
S0039½ F	1	Brake and Reverse Shaft Bracket Bushing ....	5	.....
2¼x¼ Step	16	Frame Brace Bolts ....	5	.....
¼ Step	16	Frame Brace Bolt Nuts ....	5	.....
2¼x¼	4	Rocker Plate End Bolts Front ....	5	.....
¼	8	Rocker Plate End Bolt Nuts ....	5	.....
2¼x¼ Step	12	Rocker Plate End Bolts Rear ....	5	.....
1½-12 F. Hd.	74	Rocker Plate Wood Screws—Brt. ....	Not shown	.....
3¼x¼	2	Front Spring Horn Stove Bolts ....	5	.....
¼	2	Front Spring Horn Stove Bolt Nuts ....	5	.....
3¼x¼	8	Front Spring Horn North Bolts ....	5	.....
¼	8	Front Spring Horn North Bolt Nuts ....	5	.....
¾	8	Front Spring Horn North Bolts Washers ....	5	.....
2¼x¼	2	Front Spring Horn Step Bolts ....	5	.....
¼	2	Front Spring Horn Step Bolt Nuts ....	5	.....
3¼x¾	2	Front Body Loop Machine Bolt ....	5	.....
¾	2	Front Body Loop Machine Bolt Nut ....	5	.....
3¼x¼	2	Front Body Loop North Bolt ....	5	.....
¼	2	Front Body Loop North Bolt Nut ....	5	.....
3¼x¼	2	Front Body Loop Machine Bolt ....	5	.....
¼	2	Front Body Loop Machine Bolt Nut ....	5	.....
¾	6	Front Body Loop Machine Bolt Washers ....	5	.....
2x¼	2	Brake Shaft Bracket Bolts North ....	5	.....
¼	2	Brake Shaft Bracket Bolt Nuts North ....	5	.....

## Car Frame—Continued

Stock No.	No. per Car.		Plate No.	Price.
3x $\frac{3}{8}$	4	Brake Shaft Bracket Bolts North .....	5	.....
$\frac{3}{8}$	4	Brake Shaft Bracket Bolts North Nuts .....	5	.....
$\frac{3}{8}$	4	Brake Shaft Bracket Bolts North Washers .....	5	.....
$3\frac{1}{4} \times \frac{3}{8}$	8	Rear Body Loop Machine Bolts .....	5	.....
$\frac{3}{8}$	8	Rear Body Loop Machine Bolt Nuts .....	5	.....
$\frac{3}{8}$	8	Rear Body Loop Machine Bolt Washers .....	5	.....
$3\frac{1}{4} \times \frac{3}{8}$	2	Rear Spring Horn Machine Bolts .....	5	.....
$\frac{3}{8}$	2	Rear Spring Horn Machine Bolt Nuts .....	5	.....
$\frac{3}{8}$	2	Rear Spring Horn Machine Bolt Washers .....	5	.....
$3\frac{1}{4} \times \frac{3}{8}$	4	Rear Spring Horn North Bolts .....	5	.....
$\frac{3}{8}$	4	Rear Spring Horn North Bolt Nuts .....	5	.....
$\frac{3}{8}$	4	Rear Spring Horn North Bolt Washers .....	5	.....
$3\frac{1}{4} \times \frac{3}{8}$	2	Rear Spring Horn Stove Bolts .....	5	.....
$\frac{3}{8}$	2	Rear Spring Horn Stove Bolt Nuts .....	5	.....
$2\frac{1}{4} \times \frac{1}{4}$	2	Rear Cross Support Step Bolts .....	5	.....
$\frac{1}{4}$	2	Rear Cross Support Step Bolt Nuts .....	5	.....
3x $\frac{3}{8}$	2	Rear Cross Support North Bolts .....	5	.....
$\frac{3}{8}$	2	Rear Cross Support North Bolt Nuts .....	5	.....
$\frac{1}{2} \times \frac{3}{8}$	2	Rear Cross Support Rivets .....	5	.....
00608 F	2	Center Cross Support Brackets .....	12	.....
$2\frac{1}{4} \times \frac{3}{8}$	4	Center Cross Support Bracket Bolt Steps .....	5	.....
$\frac{3}{8}$	4	Center Cross Support Bracket Bolt Nuts .....	5	.....
$1\frac{1}{2} \times \frac{3}{8}$	3	Hand Water and Air Pump Bracket Bolts— Machine .....	5	.....
$\frac{3}{8}$	3	Hand Water and Air Pump Bracket Bolt Nuts— Machine .....	5	.....
S195 E	2	Gasoline Tank Front Bracket Bolts .....	5	.....
S081 A	2	Gasoline Tank Front Bracket Bolt Nuts .....	5	.....
$1\frac{1}{2} \times \frac{3}{8}$	2	Gasoline Tank Rear Bracket Bolts Mach. ....	5	.....
$\frac{3}{8}$	2	Gasoline Tank Rear Bracket Bolts Mach. Nuts. ....	5	.....
$2\frac{1}{4} \times \frac{3}{8}$ Mach.	2	Brake Wing Bracket Bolts .....	5	.....
$\frac{3}{8}$ Mach.	2	Brake Wing Bracket Bolt Nuts .....	5	.....
$\frac{3}{8}$ Nat. Lock	2	Brake Wing Bracket Bolt Washers .....	5	.....
2x $\frac{3}{8}$	2	Cross Support Bolts No. 1 to No. 3 Machine....	5	.....
$\frac{3}{8}$	2	Cross Support Bolt Nuts .....	5	.....
$1\frac{1}{2} \times \frac{3}{8}$	3	Air Shaft Bracket Mach. Bol. ....	5	.....
$\frac{3}{8}$	3	Air Shaft Bracket Mach. Bolt Nuts .....	5	.....
1x $\frac{3}{8}$	2	Throttle Bracket Bolts .....	5	.....
$\frac{3}{8}$ Nat. Lock	2	Throttle Bracket Bolt Washers .....	5	.....
$4\frac{3}{8} \times \frac{3}{8}$	2	Engine Support Bolts Front Machine .....	5	.....
$\frac{3}{8}$	2	Engine Support Bolt Nuts .....	5	.....
$\frac{3}{8}$	2	Engine Support Bolt Washers .....	5	.....
$3\frac{1}{2} \times \frac{3}{8}$	2	Reach Rod Bracket Bolts—Machine .....	5	.....
$\frac{3}{8}$	2	Reach Rod Bracket Bolt Nuts—Machine .....	5	.....
276 F	1	Frame Strip R. H. ....	Not shown	.....
276 $\frac{1}{2}$ F	1	Frame Strip L. H. ....	Not shown	.....
276 $\frac{3}{4}$ F	1	Frame Strip Rear .....	Not shown	.....
275 F	1	Deck Board R. H. ....	Not shown	.....
275 $\frac{1}{2}$ F	1	Deck Board L. H. ....	Not shown	.....
	4	Deck Board Screws 2 $\frac{1}{2}$ -12 F. Hd. Brt. ....	Not shown	.....

# Body Strutts

Stock No.	No. per Car.		Plate No.	Price
07 F	2	Body Strutts .....	5	.....
30 C	4	Body Strutts Rod Ends .....	5	.....
So30½ C	4	Body Strutts Rod End Pins .....	5	.....
So30 C	4	Body Strutts Rod End Nuts .....	5	.....

# Brake Rod

081 F	1	Brake Pull Cable .....	5	.....
081½ F	2	Brake Pull Cable Guides .....	5	.....
84 F	2	Brake Pull Cable Ends .....	5	.....
S108 C	4	Brake Pull Cable End Screws 5/8-14-20 .....	5	.....
So31½ F	2	Brake Pull Cable End Pins .....	5	.....

# Reach Rod

008 F	1	Reach Rod .....	5	.....
So08 E	1	Reach Rod End .....	5	.....
So27 E	1	Reach Rod Bracket Bolt .....	5	.....
027 F	1	Reach Rod Bracket .....	5	.....
So27½ E	1	Reach Rod Bracket Bolt Nut .....	5	.....
So27¾ E	1	Reach Rod Bracket Bolt Lock Nut .....	5	.....
027¾ E	1	Reach Rod Bracket Spring .....	5	.....
027½ E	1	Reach Rod Bracket Washer .....	5	.....

# Condenser

443 E	1	Condenser Frame .....	6	.....
444 E	1	Condenser Bottom Cap .....	6	.....
445 E	1	Condenser Top Cap .....	6	.....
443½ E	1	Condenser Bottom Plate .....	6	.....
446 E	74	Condenser Tubes .....	6	.....
So0447 E	1	Condenser Check .....	6	.....
00447 E	1	Condenser Check Cap .....	6	.....
S446 E	1	Condenser Check Stem .....	Not shown	.....
So0447½ E	1	Condenser Check Seat .....	6	.....
00033 E	1	Condenser Overflow Pipe .....	6	.....
00600 E	1	Condenser Overflow Union Ell .....	6	.....
00330½ C	1	Condenser Overflow Union Nut 3/8 Brass .....	6	.....
00000½ E	1	Condenser Overflow Pipe Clip .....	6	.....
So600 E	2	Condenser Overflow Pipe Screws 3/4x3/8 .....	6	.....
So443 C	148	Condenser Tube Plugs .....	6	.....
448½ C	148	Condenser Tube Plug Washers .....	6	.....
444½ E	1	Condenser Bottom Gasket .....	6	.....
445½ E	1	Condenser Top Gasket .....	6	.....
00449 C	1	Condenser Pet Cock 1/4 .....	6	.....
00449½ C	1	Condenser Street Ell 1/4 .....	6	.....
448 C	1	Condenser Exhaust Tube Gland .....	6	.....
So448½ C	2	Condenser Exhaust Tube Gland Bolts .....	6	.....
So444 E	2	Condenser Cap Screws 1¼x3/8 (Filister Head)..	6	.....
So444½ E	2	Condenser Cap Screws 1½x3/8 (Filister Head)..	6	.....
So445 E	2	Condenser Cap Screws 1¾x3/8 (Filister Head)..	6	.....
So445½ E	2	Condenser Cap Screws 1½x3/8 (Filister Head)..	6	.....
So446½ E	3	Condenser Cap Screws 1¾x3/8 (Filister Head)..	6	.....



## Condenser—Continued

Stock No.		No. per Car.		Plate No.	Price.
So448	E	2	Condenser Cap Screws $3\frac{1}{2} \times \frac{5}{8}$ (Filister Head)...	6	.....
So449	E	1	Condenser Cap Screws $4\frac{1}{4} \times \frac{5}{8}$ (Filister Head)...	6	.....
108	E	1	Condenser Engine Exhaust Yoke .....	6	.....
109	E	1	Condenser Engine Exhaust Condenser End .....	6	.....
00108 $\frac{1}{2}$	E	1	Condenser Engine Exhaust Coupling $1\frac{3}{4} \times \frac{5}{8}$ ....	6	.....
So108	C	4	Condenser Engine Exhaust Cap Screws .....	6	.....
903	E	1	Condenser Hose Condenser to Pump .....	18	.....
904	E	1	Condenser Hose Pump to Water Tank .....	18	.....
00025	E	1	Condenser Hose Nipple $1\frac{1}{4} \times \frac{1}{4}$ .....	11	.....
00077 $\frac{1}{2}$	C	1	Condenser Hose Union .....	18	.....
00078	D	1	Condenser Hose Union Nut .....	18	.....
		2	Machine Bolts $2\frac{1}{4} \times \frac{3}{8}$ .....	Not shown	.....
		2	Machine Bolt Nuts $\frac{3}{8}$ .....	Not shown	.....
		2	$\frac{3}{8}$ Iron Washers .....	Not shown	.....
		2	$\frac{3}{8}$ National Lock Washers .....	Not shown	.....

## Condenser Fan

0292	E	3	Condenser Fan Blades .....	6	.....
291	E	1	Condenser Fan Spider .....	6	.....
		12	Condenser Fan Blade Rivets .....	Not shown	.....
So291	E	1	Condenser Fan Cone .....	6	.....
So291 $\frac{1}{4}$	E	1	Condenser Fan Cup .....	6	.....
So291 $\frac{1}{2}$	E	1	Condenser Fan Cone Adjusting .....	6	.....
So291 $\frac{3}{4}$	E	1	Condenser Fan Lock Nut .....	6	.....
So290	E	1	Condenser Fan Bracket Stud .....	6	.....
0291 $\frac{1}{2}$	E	1	Condenser Fan Cone Ball Retainer .....	6	.....
298	E	1	Condenser Fan Belt $2-4\frac{1}{2}$ .....	6	.....
290	E	1	Condenser Fan Bracket .....	6	.....
So289	E	1	Condenser Fan Pulley Shaft .....	6	.....
0290 $\frac{3}{4}$	E	1	Condenser Fan Top Stud .....	6	.....
So81	A	2	Condenser Fan Top Stud Nut .....	6	.....
00290 $\frac{1}{2}$	E	1	Condenser Fan Pulley Shaft Bushing .....	6	.....
0099	C	1	Condenser Fan Pulley Shaft Grease Cup .....	6	.....
289	E	1	Condenser Fan Pulley .....	6	.....
S289 $\frac{1}{4}$	E	1	Condenser Fan Pulley Set Screws $\frac{1}{4} \times \frac{1}{2}$ .....	6	.....
S289 $\frac{1}{2}$	E	1	Condenser Fan Pulley Shaft Blind Screw .....	6	.....
0366 $\frac{1}{4}$	E	1	Condenser Fan Extension Shaft .....	6	.....
$3\frac{1}{2} \times \frac{5}{8}$		1	Condenser Fan Bracket Bottom Bolt .....	Not shown	.....
$\frac{3}{8}$		2	Condenser Fan Bracket Bottom Bolt Nuts .....	Not shown	.....
So291 $\frac{3}{4}$	E	1	Condenser Fan Bracket Cone Lock Nut .....	6	.....

## Engine

00187	F	1	Rocker Shaft Lever (By Pass) .....	7	.....
So187	C	1	Rocker Shaft Lever Set Screw .....	7	.....
00166	C	1	Rocker Shaft Bracket .....	7	.....
00162	C	1	Rocker Shaft Bracket Gasket .....	7	.....
So105	A	2	Rocker Shaft Bracket Screws .....	8	.....
0173	D	1	By Pass Rocker Shaft .....	7	.....
174	D	1	Rocker Shaft Poppet Valve Lever .....	7	.....
So120	D	1	Rocker Shaft Poppet Valve Lever Wedge Pin...	7	.....

# Engine—Continued

Stock No.		No. per Car.		Plate No.	Price
So81	A	1	Rocker Shaft Poppet Valve Lever Wedge Pin Nut .....	7	.....
078	C	1	Engine Starting Spring .....	7	.....
So77	E	1	Engine Starting Spring Cotter Pin .....	7	.....
00149	C	1	Poppet Valve Stem—Long .....	7	.....
00148	C	1	Poppet Valve Stem—Short .....	7	.....
00148½	C	4	Poppet Valve Stem Collars .....	7	.....
00149½	C	2	Poppet Valves .....	7	.....
So43	A	2	Poppet Valve Stem Nuts .....	7	.....
00144	A	2	Poppet Valve Stem Stuffing Boxes .....	7	.....
00145	A	2	Poppet Valve Stem Stuffing Box Glands .....	7	.....
00146	A	2	Poppet Valve Stem Stuffing Box Nuts .....	7	.....
00141	C	2	Poppet Valve Caps .....	7	.....
100	E	1	Engine Frame .....	9	.....
101	E	1	Engine Frame Cap .....	9	.....
103	E	1	Engine Frame Side Plate .....	9	.....
101½	E	1	Engine Frame Drum Shield .....	9	.....
So167	C	6	Engine Frame Drum Shield Screws 5/8-14-20 .....	8	.....
So107	C	4	Engine Frame Side Plate Screws 5/8-14-20 .....	8	.....
00103½	E	1	Engine Frame Oil Tube .....	9	.....
So103	E	1	Engine Frame Oil Tube Post .....	9	.....
105	C	1	Engine Cylinder .....	9	.....
106	C	1	Engine Cylinder Head H. P. .....	9	.....
106½	C	1	Engine Cylinder Head L. P. .....	9	.....
107	C	1	Engine Steam Chest Cover .....	9	.....
So105	A	60	Engine Cylinder Screws .....	9	.....
167	C	1	Engine Cylinder Cover—Aluminum R. H. Side .....	8	.....
167½	C	1	Engine Cylinder Cover—Aluminum L. H. Side .....	8	.....
168	C	1	Engine Cylinder Cover—Aluminum Front Top .....	8	.....
168½	C	1	Engine Cylinder Cover—Aluminum Rear Top .....	8	.....
169	C	1	Engine Cylinder Cover—Aluminum R. H. Bottom .....	8	.....
169½	C	1	Engine Cylinder Cover—Aluminum L. H. Bottom .....	8	.....
So167½	C	15	Engine Cylinder Cover Screws 5/8-12-24 .....	8	.....
So168	C	4	Engine Cylinder Cover Screws 1-12-24 .....	8	.....
00327¼	F	1	Engine Cylinder Plug H. P. .....	8	.....
00327½	E	1	Engine Cylinder Plug L. P. .....	8	.....
00029	C	1	Engine Cylinder Oil Connection .....	8	.....
00163	F	1	Engine By Pass Bracket .....	7	.....
So163	F	1	Engine By Pass Valve .....	7	.....
0165	F	1	Engine By Pass Bracket Spring .....	7	.....
0165½	F	1	Engine By Pass Bracket Spring Washer .....	7	.....
00460	A	1	Engine By Pass Bracket Gland .....	7	.....
00161	C	1	Engine By Pass Bracket Gasket .....	7	.....
So162	C	1	Engine By Pass Bracket Blind Screw .....	7	.....
So105	A	7	Engine By Pass Bracket Screws .....	8	.....
187½	F	1	Engine By Pass Yoke .....	7	.....
187	F	1	Engine By Pass Yoke Lever .....	7	.....
00160	C	1	Engine Steam Chest Cover Gasket .....	7	.....
00158	A	2	Engine Cylinder Head Gaskets H. P. .....	7	.....

## Engine—Continued

Stock No.	No. per Car.		Plate No.	Price.
00158½ C	2	Engine Cylinder Head Gaskets L. P. ....	7	.....
189 D	1	Engine Rocker Shaft Starting Lever .....	7	.....
S0129 D	1	Engine Rocker Shaft Starting Lever Wedge Pin .....	7	.....
S081 A	1	Engine Rocker Shaft Starting Lever Wedge Pin Nut .....	7	.....
00123 E	1	Engine Cross Head Slide H. P. ....	9	.....
00123½ E	1	Engine Cross Slide L. P. ....	9	.....
0104 B	4	Engine Tie Rods .....	9	.....
0104½ C	4	Engine Tie Rod Lock Washers .....	9	.....
S035 A	8	Engine Tie Rod Nuts .....	9	.....
00386 A	3	Engine Casing Filling Plugs .....	9	.....
00386 A	2	Engine Frame Cap Plugs .....	9	.....
00484 C	1	Engine Casing Oil Connection .....	8	.....
112 C	1	Engine Slide Valve H. P. ....	7	.....
112½ C	1	Engine Slide Valve L. P. ....	7	.....
0143 E	2	Engine Slide Valve Stem .....	7	.....
S043 A	2	Engine Slide Valve Stem Lock Nuts .....	7	.....
S0147½ B	2	Engine Slide Valve Stem Bearing Bushings .....	7	.....
S0101½ C	2	Engine Link Oil Splashes .....	9	.....
00144 A	2	Engine Slide Valve Stem Stuffing Box Glands...	7	.....
00146 A	2	Engine Slide Valve Stem Stuffing Box Nuts ...	7	.....
00145 A	2	Engine Slide Valve Stem Stuffing Boxes .....	7	.....
0115 E	1	Engine Piston Head H. P. ....	9	.....
0115½ E	1	Engine Piston Head L. P. ....	9	.....
117 E	2	Engine Piston Head Rings H. P. ....	9	.....
117½ E	2	Engine Piston Head Rings L. P. ....	9	.....
0118 E	2	Engine Piston Rods .....	9	.....
S0118 A	2	Engine Piston Rod Nuts .....	9	.....
0118½ C	2	Engine Piston Rod Lock Washers .....	9	.....
00119 A	2	Engine Piston Rod Stuffing Boxes .....	7	.....
00120 A	2	Engine Piston Rod Stuffing Box Glands .....	7	.....
00121 A	2	Engine Piston Rod Stuffing Box Nuts .....	7	.....
110 E	1	Engine Girt—R. H. Front .....	9	.....
111 E	1	Engine Girt—L. H. Front .....	9	.....
112 E	1	Engine Girt—R. H. Rear .....	9	.....
113 E	1	Engine Girt—L. H. Rear .....	9	.....
S0110 E	4	Engine Girt Tie Rods .....	9	.....
S0111½ E	4	Engine Girt Tie Rod Washers .....	Not shown	.....
S0111 E	4	Engine Girt Bolts .....	9	.....
S035 A	8	Engine Girt Bolt Nuts .....	9	.....
S055 C	16	Engine Girt Tie Rod Nuts .....	9	.....
071 E	1	Engine Front Universal Joint Case .....	9	.....
151 E	1	Engine Brake Drum .....	9	.....
S0131 E	3	Engine Brake Drum Screws .....	7	.....
S0131½ E	1	Engine Brake Drum Screws .....	7	.....
S036 C	4	Engine Brake Drum Screw Nuts .....	7	.....
0151½ E	2	Engine Brake Drum Washers .....	7	.....
00366¾ E	1	Engine Oil Belt Pulley .....	9	.....
S0151 E	1	Engine Main Bearing Flange Cone .....	7	.....

## Engine—Continued

11

Stock No.		No. per Car.		Plate No.	Price.
0128	E	1	Engine Main Bearing Thrust Cup .....	7	.....
0128½	E	1	Engine Main Bearing Thrust Cup (Plain Ht.)..	7	.....
S0128	D	12	Engine Main Bearing Thrust Cup Screws .....	7	.....
0129	E	3	Engine Main Bearing Cups (Plain) .....	7	.....
0130	E	2	Engine Main Bearing Cones .....	7	.....
S0150	A	1	Engine Main Bearing Cone Taper Pin .....	7	.....
0120	E	1	Engine Crank H. P. (Inner) .....	7	.....
0126¼	E	1	Engine Crank H. P. (Outer) .....	7	.....
0126½	E	1	Engine Crank L. P. (Outer) .....	7	.....
S0126	E	1	Engine Crank H. P. Tie Pin .....	7	.....
0137	A	1	Engine Crank Air Pump Connecting Rod Cone	8	.....
0138	A	1	Engine Crank Air Pump Connecting Rod Cone	8	.....
			Lock Nut .....	8	.....
0139	A	1	Engine Crank Air Pump Connecting Rod Cone	8	.....
			Washer .....	8	.....
0150	E	1	Engine Eccentric .....	7	.....
S0150	A	2	Engine Eccentric Taper Pins .....	7	.....
0137½	H	2	Engine Connecting Rod Cones .....	7	.....
0127	E	2	Engine Connecting Rods .....	7	.....
S0127	C	4	Engine Connecting Rod Screws .....	7	.....
S036	C	4	Engine Connecting Rod Screw Nuts .....	7	.....
0127½	C	4	Engine Connecting Rod Screw Lock Washers...	7	.....
0152	C	4	Engine Eccentric Rods .....	7	.....
S0152	C	8	Engine Eccentric Rod Screws .....	7	.....
S0152½	C	8	Engine Eccentric Rod Nuts .....	7	.....
S0147	C	4	Engine Eccentric Rod Pins 1- $\frac{11}{16}$ - $\frac{1}{16}$ .....	7	.....
S0147	A	2	Engine Eccentric Rod Pins $\frac{11}{16}$ - $\frac{1}{16}$ .....	7	.....
153	E	2	Engine Eccentric Links .....	7	.....
S0153	C	2	Engine Eccentric Link Pins 1 $\frac{1}{8}$ - $\frac{1}{16}$ .....	7	.....
S042	A	2	Engine Eccentric Link Pin Washers .....	7	.....
154	C	2	Engine Eccentric Link Levers .....	7	.....
S0154	C	1	Engine Eccentric Link Lever Pin 3 $\frac{1}{4}$ x $\frac{1}{16}$ .....	7	.....
0150	A	2	Engine Eccentric Link Blocks .....	7	.....
0193	C	1	Engine Pump Eccentric Rod .....	7	.....
S0152	C	2	Engine Pump Eccentric Rod Screws .....	7	.....
S0152½	C	2	Engine Pump Eccentric Rod Screw Nuts .....	7	.....
0122	C	2	Engine Cross Heads .....	7	.....
S0122	C	4	Engine Cross Head Lock Screws .....	7	.....
S081	A	4	Engine Cross Head Lock Screw Nuts .....	7	.....
0124	C	2	Engine Cross Head Pins .....	7	.....
S0124	F	1	Engine Cross Head Condenser Pump Pin.....	8	.....
0381	E	1	Engine Air Pump Connecting Rod .....	8	.....
S0152	A	2	Engine Air Pump Connecting Rod Screws .....	8	.....
0383	E	1	Engine Air Pump Connecting Rod Cross Head..	8	.....
S0381	E	1	Engine Air Pump Connecting Rod Cross Head	8	.....
			Pin .....	8	.....
0381½	E	1	Engine Air Pump Connecting Rod Cross Head	8	.....
			Pin Washer .....	8	.....
S0383½	E	1	Engine Air Pump Connecting Rod Cross Head	8	.....
			Blind Screw .....	8	.....

## Engine—Continued

Stock No.		No. per Car.		Plate No.	Price.
So383	F	2	Engine Air Pump Connecting Rod Cross Head Lock Screw .....	8	.....
0147	C	2	Engine Valve Stem Bearings .....	7	.....
134	E	1	Engine Main Bearing Cap—Large .....	9	.....
135	E	2	Engine Main Bearing Cap—Small .....	9	.....
So135	E	2	Engine Main Bearing Cap Bolts .....	9	.....
0104½	C	2	Engine Main Bearing Cap Lock Washers .....	9	.....
078	C	1	Engine Starting Spring .....	7	.....
155	C	1	Engine Link Rocker Lever .....	7	.....
So167½	C	2	Engine Link Rocker Lever Screws .....	8	.....
So155	C	1	Engine Link Rocker Lever Pin 7-3/8 .....	7	.....
0184	C	1	Engine Reverse Rod 4¼" .....	8	.....
185	C	2	Engine Reverse Rod Ends .....	8	.....
So185	C	2	Engine Reverse Rod End Blocks .....	8	.....
So184	C	2	Engine Reverse Rod End Pins 2x3/8 .....	8	.....
So52	C	2	Engine Reverse Rod End Pins 1-1/4-1/4 .....	8	.....
So81	A	2	Engine Reverse Rod End Nuts .....	8	.....
183½	C	1	Engine Reverse Lever .....	8	.....
So183	C	1	Engine Reverse Lever Pin 3-1/2 .....	8	.....
00382	E	1	Engine Air Pump Cross Head Slide .....	8	.....
So131	C	2	Engine Air Pump Cross Head Slide Bolts .....	8	.....
00384	E	1	Engine Air Pump Cross Head Slide Cap .....	8	.....
So167	C	14	Engine Air Pump Cross Head Slide Screws .....	8	.....
00385	E	1	Engine Air Pump Inlet Chamber .....	8	.....
00387	E	1	Engine Air Pump Outlet Chamber .....	8	.....
385½	E	1	Engine Air Pump Inlet and Outlet Valve Clamp .....	8	.....
So385	E	1	Engine Air Pump Inlet and Outlet Valve Clamp Bolt 2¼x3/8 .....	8	.....
00387½	E	1	Engine Air Pump Screen .....	8	.....
38-10-24		1	Engine Air Pump Screen Screw .....	Not shown	.....
388	E	1	Engine Air Pump Valve Lifting Lever .....	8	.....
So31½	C	1	Engine Air Pump Valve Lifting Lever Pin .....	8	.....
So147	C	1	Engine Air Pump Lifting Lever Connecting Pin .....	8	.....
00391	E	1	Engine Air Pump Inlet Valve Seat .....	8	.....
00391½	E	1	Engine Air Pump Outlet Valve Seat .....	8	.....
So391	E	2	Engine Air Pump Valve Seat Pins .....	8	.....
0394	E	2	Engine Air Pump Valve Seat Springs .....	8	.....
0302	E	2	Engine Air Pump Valve Seat Washers—Small .....	8	.....
0393	E	2	Engine Air Pump Valve Seat Washers—Large .....	8	.....
0216½	E	1	Engine Air Pump Shaft Pull Lever Spring .....	8	.....
00340	FF	1	Condenser Pump Barrel .....	8	.....
00341	F	1	Condenser Pump Barrel Plug .....	8	.....
So326	FF	2	Condenser Pump Checks .....	8	.....
00340½	FF	2	Condenser Pump Check Caps .....	8	.....
0345	FF	1	Condenser Pump Piston Rod .....	8	.....
So81	A	1	Condenser Pump Piston Rod Nut .....	8	.....
0346	FF	1	Condenser Pump Piston Rod Head .....	8	.....
00349	F	1	Condenser Pump Piston Rod End .....	8	.....

## Engine—Continued

13

Stock No.	No. per Car.		Plate No.	Price.
S0349	F	1		
		Condenser Pump Piston Rod End Binder		
		Screw $\frac{3}{8} \times \frac{1}{4} \times 20$ Filister Hd. ....	8	
00325	$\frac{1}{2}$ F	1		
		Lower Water Pump Casting .....	8	
S00325	C	1		
		Lower Water Pump Cast Screw Plug .....	8	
00326	A	2		
		Lower Water Pump Ball Checks .....	8	
S0326	C	2		
		Lower Water Pump Ball Check Seats .....	8	
00327	C	2		
		Lower Water Pump Ball Check Caps .....	8	
00328	C	2		
		Lower Water Pump Ball Check Gaskets .....	8	
S0340	C	1		
		Lower Water Pump Lock Nut $1\frac{1}{4}$ -20 .....	8	
00121	A	1		
		Lower Water Pump Stuffing Box Nut $\frac{1}{2}$ .....	8	
00120	A	1		
		Lower Water Pump Stuffing Box Gland $\frac{1}{8}$ .....	8	
00325	E	1		
		Upper Water Pump Casting .....	8	
S00325	C	1		
		Upper Water Pump Screw Plug .....	8	
00326	A	2		
		Upper Water Pump Ball Checks .....	8	
S326	C	2		
		Upper Water Pump Ball Check Seats .....	8	
00327	C	1		
		Upper Water Pump Ball Check Cap .....	8	
00328	C	1		
		Upper Water Pump Ball Check Gasket .....	8	
00327	E	1		
		Upper Water Pump By Pass Ball Check Cap .....	8	
00328	C	1		
		Upper Water Pump By Pass Check Gasket .....	8	
S0194	C	1		
		Upper Water Pump Lock Nut .....	8	
00120	E	1		
		Upper Water Pump Stuffing Box Gland $\frac{1}{8}$ .....	8	
00121	E	1		
		Upper Water Pump Stuff Box Adj. Nut $\frac{1}{8}$ .....	8	
00329	C	1		
		Union End .....	8	
00330	C	1		
		Union End Nut .....	8	
0331	F	1		
		Pump Plunger .....	8	
S0331	D	1		
		Pump Plunger Block .....	8	
S0176	C	1		
		Pump Plunger Rocker Pin—Short $1\frac{1}{8} \times \frac{7}{16}$ .....	7	
S0176 $\frac{1}{2}$	D	1		
		Pump Plunger Rocker Pin—Long .....	7	
0172	D	1		
		Pump Rocker .....	7	
S0172	C	1		
		Pump Rocker Bearing Pin .....	7	
S0172 $\frac{1}{2}$	C	2		
		Pump Rocker Bearing Pin Set Screws .....	7	
S055	C	2		
		Pump Rocker Bearing Pin Set Screws Nuts .....	7	
194	C	1		
		Pump Bracket .....	8	
S0105	A	4		
		Pump Bracket Screws .....	8	
620	E	1		
		Engine Apron Complete .....	10	
621	F	1		
		Engine Apron R. H. ....	10	
621 $\frac{1}{2}$	E	1		
		Engine Apron L. H. ....	10	
622	E	1		
		Engine Apron Throttle Casting .....	10	
624	F	1		
		Engine Apron Reverse Lever Casting .....	10	
625	E	1		
		Engine Apron Overflow Pipe Casting .....	10	
626	E	1		
		Engine Apron By Pass Pipe Casting .....	10	
627	E	1		
		Engine Apron By Pass Hose Casting .....	10	
628	E	1		
		Engine Apron Condenser Hose Casting .....	10	
620	E	1		
		Engine Apron Lower Water Pump Casting .....	10	
35	E	1		
		Foot Brake Lever .....	10	
S0129	D	1		
		Foot Brake Lever Wedge Pin .....	10	
S081	A	1		
		Foot Brake Lever Wedge Pin Nut .....	10	
036	E	1		
		Foot Brake Lever Shaft .....	10	
0036 $\frac{1}{2}$	E	2		
		Foot Brake Lever Shaft Bushing .....	10	

## Engine—Continued

Stock No.	No. per Car.		Plate No.	Price.
35½ E	1	Foot Brake Lever Shaft Lever .....	10	.....
So129 D	1	Foot Brake Lever Shaft Lever Wedge Pin .....	10	.....
So81 A	1	Foot Brake Lever Shaft Lever Wedge Pin Nut .....	10	.....
035¼ E	2	Foot Brake Rod 2 .....	10	.....
185 C	2	Foot Brake Rod Ends .....	10	.....
So185 C	2	Foot Brake Rod Ends Blocks .....	10	.....
So184 C	2	Foot Brake Rod Ends Pins .....	10	.....
So52 C	2	Foot Brake Rod Ends Pins .....	10	.....
So81 A	2	Foot Brake Rod Ends Nuts .....	10	.....
199 E	1	Foot Brake Wing Lever .....	10	.....
So129 D	1	Foot Brake Wing Lever Wedge Pin .....	10	.....
So81 A	1	Foot Brake Wing Lever Wedge Pin Nut .....	10	.....
37 F	1	Foot Brake Wing Lever Bracket .....	5	.....
So037 E	2	Foot Brake Wing Lever Bracket Bushings .....	5	.....
037½ E	2	Foot Brake Wing Lever Bracket Shims .....	10	.....
076¼ E	1	Foot Brake Wing .....	10	.....
076½ E	1	Foot Brake Wing Plate .....	10	.....
0075 E	1	Foot Brake Ring .....	7	.....
075¾ E	1	Foot Brake Ring Spring .....	7	.....
So75 E	1	Foot Brake Ring Adj. Screw .....	7	.....
102 E	1	Foot Brake Ring Finger Bracket .....	9	.....
So102 E	2	Foot Brake Ring Finger Bracket Screws .....	9	.....
0102½ E	1	Foot Brake Ring Finger Bracket Locker Washer .....	9	.....
	6	Engine Apron Screws ¾x12 Bld. Rd. Hd. Wood	Not shown	.....
0630 E	2	Engine Apron Clips .....	10	.....
½-4 E	2	Engine Apron Clips Screws ½x4 .....	Not shown	.....
½-10-24	2	Engine Apron Clips Screws (Machine) .....	Not shown	.....
14x24	2	Engine Apron Clips Screws Nuts .....	Not shown	.....

## Engine Shield

700 F	1	Engine Shield (Aluminum) .....	10	.....
1¼x½	2	Engine Shield Machine Bolts .....	10	.....
½	2	Engine Shield Machine Bolts Nuts .....	10	.....

## Hood

	1	Car Hood Complete .....	Not shown	.....
631 E	2	Car Hood Screens .....	Not shown	.....
0634 E	2	Car Hood Inner Braces .....	Not shown	.....
0633 E	2	Car Hood Screen Mouldings .....	Not shown	.....
0604 E	2	Car Hood Hinges .....	10	.....
	4	Car Hood Hinges Rivets .....	Not shown	.....
00604½ E	2	Car Hood Hinges Lugs .....	10	.....
So604 E	2	Car Hood Hinges Pins .....	10	.....
So604½ E	2	Car Hood Hinges Tie Rods .....	10	.....
0604¾ E	2	Car Hood Hinges Tie Rods Washers .....	10	.....
So81 A	2	Car Hood Hinges Tie Rods Nuts .....	10	.....
So604¾ E	2	Car Hood Hinges Tie Rods Ornamental Nuts .....	10	.....
0602 E	2	Car Hood Catches .....	10	.....

## Hood—Continued

Stock No.	No. per Car.		Plate No.	Price.
00601 E	2	Car Hood Catches Sockets	10	.....
00602 1/2 E	2	Car Hood Catches Springs	10	.....
S0602 1/2 E	2	Car Hood Catches Springs Washers	10	.....
S00602 E	2	Car Hood Catches Springs Screws	10	.....
00603 E	2	Car Hood Catches Plates	10	.....
S00603 E	4	Car Hood Catches Plates Screws	10	.....
0606 E	1	Car Hood Lift Rod	10	.....
1x12 R.H.	1	Car Hood Lift Rod Blued Screw	Not shown	.....
1/4	1	Car Hood Lift Rod Blued Screw Washer	Not shown	.....
3/8-10-24	4	Car Hood Brace Screws	Not shown	.....
10-24	4	Car Hood Brace Screws Nuts	Not shown	.....
3/8-4 Rd.Hd.	2	Car Hood Brace Screws Small	Not shown	.....
00863 E	2	Car Hood Handles	10	.....

## Water Regulator

00450 E	1	Water Regulator Casting	11	.....
00451 E	1	Water Regulator Flange	11	.....
S0451 E	14	Water Regulator Flange Screws—Short 3/4x1 1/2 Filister	11	.....
S0451 1/2 E	2	Water Regulator Flange Screws—Long 1x1 1/2 Filister	11	.....
00452 C	1	Water Regulator Stem	11	.....
00453 C	1	Water Regulator Stem Cap	11	.....
00454 C	1	Water Regulator Adj. Screw	11	.....
S00452 C	1	Water Regulator Adj. Lock Nut	11	.....
00455 C	1	Water Regulator Stem Adj. Worm	11	.....
00456 C	1	Water Regulator Stem Adj. Worm Screw	11	.....
0457 C	1	Water Regulator Spring	11	.....
00459 A	1	Water Regulator Stuffing Box Nut	11	.....
00458 A	1	Water Regulator Stuffing Box	11	.....
00460 A	1	Water Regulator Stuffing Box Gland	11	.....
00463 E	1	Water Regulator Diaphragm	11	.....
461 C	1	Water Regulator Valve	11	.....
S401 C	1	Water Regulator Valve Seat	11	.....
402 C	1	Water Regulator Lever	11	.....
S00462 C	1	Water Regulator Lever Pin	11	.....
00464 E	1	Water Regulator Diaphragm Washer	11	.....
00465 D	1	Water Regulator Strainer	11	.....
00327 C	2	Water Regulator Check Caps	11	.....
00328 C	2	Water Regulator Check Caps Washers	11	.....

## Water Regulator Lines

00613 E	1	By Pass Nipple 1/8x1 1/2 Brass	11	.....
00612 E	1	By Pass Tee 1/4x1/8x1/8 Brass	11	.....
00937 E	1	By Pass Pipe to Upper Pump 1/8x5/4 Brass	11	.....
0538 A	1	By Pass Union End 1/2 Steel	11	.....
0539 C	1	By Pass Union End Nut 1/2 Steel	11	.....
00925 E	1	By Pass Pipe Nipple 1/4x1 1/4 Brass	11	.....
00977 1/2 A	1	By Pass Union End Female (Ground) 1/4	11	.....
00978 D	1	By Pass Union End Nut (Ground) 1/4	11	.....



## Water Regulator Lines—Continued

Stock No.	No. per Car.		Plate No.	Price.
00904½ C	1	By Pass Union End Hose ¼x2½ Brass Spec. . . . .	11	.....
926 E	1	By Pass Hose to Lower Pump . . . . .	11	.....
00958 E	1	By Pass Pipe (Lower Pump to Upper) ¼x1½ Brass . . . . .	11	.....
00977 D	2	By Pass Pipe Union Ends ¼ Brass . . . . .	11	.....
00978 D	2	By Pass Pipe Union Nuts ¼ Brass . . . . .	11	.....
00939 E	1	Steam Line to Water Regulator 45¼x¼ Brass. . . . .	11	.....
0538 C	2	Union Ends (½ Steel Unions) . . . . .	11	.....
0539 C	2	Union Ends (¾ Steel) . . . . .	11	.....
S0939 C	1	Pipe Clip . . . . .	11	.....
	1	Pipe Clip Screw ⅝x8 Rd. Hd. . . . .	Not shown	.....

## Water Tank

	1	Water Tank Complete . . . . .	Not shown	.....
496	1	Water Tank Bracket to Frame R. H. . . . .	12	.....
496½	1	Water Tank Bracket to Frame L. H. . . . .	12	.....
00567 C	1	Water Tank Cover . . . . .	12	.....
00568 C	1	Water Tank Cover Catch . . . . .	12	.....
00569 C	1	Water Tank Cover Knob . . . . .	12	.....
0570 C	1	Water Tank Cover Knob Stud . . . . .	12	.....
S0570 C	1	Water Tank Cover Knob Washer . . . . .	12	.....
0571 C	1	Water Tank Cover Knob Spring . . . . .	12	.....
00565 C	1	Water Tank Cover Knob Flange . . . . .	12	.....
⅝-10-24	10	Water Tank Cover Flange Screws Brass Mach. . . . .	Not shown	.....
00566 C	1	Water Tank Cover Flange Washer . . . . .	12	.....
12-24	10	Water Tank Cover Flange Screw Nut . . . . .	Not shown	.....
00560 A	2	Water Tank Cover Floats . . . . .	12	.....
00561 E	2	Water Tank Cover Floats Caps . . . . .	12	.....
560½ A	2	Water Tank Cover Floats Washer Fibers. . . . .	12	.....
561½ A	2	Water Tank Cover Floats Washer Rubbers . . . . .	12	.....
00950½ E	1	Water Tank Oil Float Pipe Nipple (1¼x¼) . . . . .	12	.....
00950 E	1	Water Tank Oil Float Pipe ½x20 Brass Tubes. . . . .	12	.....
00977½ A	1	Water Tank Oil Float Pipe Union End ¼ . . . . .	11	.....
00560 E	1	Water Tank Oil Float Bracket in Tank. . . . .	Not shown	.....
00572 F	1	Water Tank Bottom Plug . . . . .	12	.....
572½ C	1	Water Tank Bottom Plug Washer . . . . .	12	.....
S00572 C	1	Water Tank Bottom Ring . . . . .	Not shown	.....
00563 A	1	Water Tank Bottom Strainer . . . . .	12	.....
00562 A	1	Water Tank Bottom Well . . . . .	12	.....
564½ A	1	Water Tank Bottom Yoke . . . . .	12	.....
S0564 A	1	Water Tank Bottom Set Screw . . . . .	12	.....
563½ A	1	Water Tank Bottom Gasket . . . . .	12	.....
906 E	1	Water Tank Strainer Hose 10x⅜ . . . . .	11	.....
00482 A	1	Water Tank Strainer Hose Union ¼ S. Line B. . . . .		.....
00978 D	1	Water Tank Strainer Union Nut ¼ . . . . .	11	.....
S00495 C	2	Water Tank Screw ⅞-24-16 . . . . .	12	.....
S00496 C	2	Water Tank Screw Washers . . . . .	12	.....
00607 C	3	Water Tank Prong Brackets . . . . .	Not shown	.....
00680 F	1	Water Tank Overflow Pipe . . . . .	12	.....

## Water Tank—Continued

17

Stock No.	No. per Car.		Plate No.	Price.
0681 F	1	Water Tank Overflow Pipe Funnel	Not shown	
00572 F	1	Water Tank Overflow Pipe Plug	12	
682 F	1	Water Tank Overflow Pipe Hose	12	
00665 E	1	Water Tank Grease Cup Bracket	12	
00665½ E	1	Water Tank Grease Cup Pipe	12	
0099 C	1	Water Tank Grease Cup	12	
0099½ C	1	Water Tank Grease Cup Cap	12	
S00413 A	1	Water Tank Grease Cup Pipe Gland	12	
S00414 A	1	Water Tank Grease Cup Pipe Nut	12	

### Dash

274 E	1	Wood Dash	Not shown	
272 E	1	R. H. Iron	13	
272½ E	1	L. H. Iron	13	
	2	Stove Bolts ½x3	Not shown	
	2	Stove Bolts ½x3½	Not shown	
	8	Stove Bolts Nuts ½	Not shown	
¾	3	Stove Bolts Washers	Not shown	
	1	F. H. Wood Screw 1½x12 Bright	Not shown	
	10	Stove Bolts 1½x½	Not shown	
273 E	1	Pc. Dash Moulding	13	

### Steering Rod

028 F	1	Steering Rod 27"x1 Dia.	5	
029 F	1	Steering Rod 47½"x1"	5	
31 F	1	Steering Swivel Joint Case R. H.	5	
31½ F	1	Steering Swivel Joint Case L. H.	5	
031¼ F	2	Steering Swivel Joint Case Springs	5	
033 F	2	Steering Swivel Joint Case Plugs	5	
032 F	4	Steering Swivel Joint Case Sockets	5	
S0109 A	4	Steering Swivel Joint Binder Screws	5	
30 F	2	Steering Rod Ends	5	
S030½ F	2	Steering Rod Ends Pins	5	
S0109 A	2	Steering Rod Binder Screws	5	
899 F	1	Steering Rod Joint Cover R. H.	5	
899½ F	1	Steering Rod Joint Cover L. H.	5	

### Steps

240¼ F	1	Side Step Board R. H.	Not shown	
241¼ F	1	Side Step Board L. H.	Not shown	
0240 F	6	Side Step Irons	13	
245 F	1	Side Step Mat R. H.	Not shown	
00245½ F	2	Side Step Mat Mouldings 66"	Not shown	
246 F	1	Side Step Mat L. H.	Not shown	
00245¾ F	2	Side Step Mat Mouldings 71"	Not shown	
2½x½	18	Side Step Bolts (North)	5	
½	18	Side Step Bolts Nuts (North)	5	
1¾x¼	6	Side Step Bolts (North)		
1¼x¼	6	Side Step Bolts (North)	5	
¼	12	Side Step Bolts Nuts (North)	5	

## Steps—Continued

Stock No.	No. per Car.		Plate No.	Price
00854 F	1	Side Step Mud Guard Cleat—Front R. H.	13	
00854½ F	1	Side Step Mud Guard Cleat—Front L. H.	13	
00855 F	2	Side Step Mud Guard Cleat—Rear	13	
58-14-20	8	Side Step Mud Guard Cleat Screws	Not shown	
1½-14-20	8	Side Step Mud Guard Cleat Screws	Not shown	

## Oil Pump

350 E	1	Oil Pump Base	15	
351 E	1	Oil Pump Cover (Cyl. Oil)	15	
353 C	1	Oil Pump Name Plate	15	
352 E	1	Oil Pump Cover (Eng. Oil)	15	
351½ E	2	Oil Pump Glasses	15	
S0350 E	4	Oil Pump Cap Studs	15	
351¾ E	4	Oil Pump Glass Gaskets	15	
S0353 C	4	Oil Pump Name Plate Screws ¼-12-24	15	
S0355 C	4	Oil Pump Valve Lug Screws ¼-12-24	15	
S00351 C	2	Oil Pump Cover Filling Plugs	15	
00354 C	1	Oil Pump Valve Lug R. H. (Cyl. Oil)	15	
00355 D	1	Oil Pump Valve Lug L. H. (Eng. Oil)	15	
S0354 C	4	Oil Pump Valve Lug Valves	15	
0355½ C	4	Oil Pump Valve Lug Springs	15	
0356 E	2	Oil Pump Plunger Rods	15	
0357 C	2	Oil Pump Plunger Rods Knob Flanges	Not shown	
358 C	2	Oil Pump Plunger Rods Knobs	15	
S0358 A	2	Oil Pump Plunger Rods Knobs Screws	15	
00360 A	2	Oil Pump Plunger Shut Off Valves	15	
00361 A	2	Oil Pump Plunger Shut Off Valves Caps	15	
0362 A	1	Oil Pump Plunger Shut Off Valves Keys	15	
00386 A	2	Oil Pump Plunger Shut Off Valves Screw Plugs	15	
00386¼ C	2	Oil Pump Plunger Shut Off Valve Screw Plugs	15	
00386½ A	4	Oil Pump Plunger Shut Off Valve Plug Gaskets	15	
00374 C	2	Oil Pump Shell Plugs ⅝"	15	
00363½ C	1	Oil Pump Worm	15	
00363 C	1	Oil Pump Worm Wheel	15	
S0363 C	1	Oil Pump Worm Shaft	15	
S0363½ C	1	Oil Pump Worm Collar	15	
00364 C	2	Oil Pump Plunger Heads	15	
S0364 C	1	Oil Pump Plunger ¾"	15	
S0364½ C	1	Oil Pump Plunger 1¼"	15	
00365 C	2	Oil Pump Plunger Cranks	15	
S0365 C	1	Oil Pump Plunger Cranks Shaft	15	
0366 E	1	Oil Pump Driving Shaft	15	
0366½ E	1	Oil Pump Driving Shaft Extension	15	
367 F	1	Oil Pump Pulley	15	
367½ F	1	Oil Pump Belt	15	
0299 E	1	Oil Pump Belt Connection	15	
	3	Oil Pump Bolt for Dash Support 18¼ Cge	Not shown	
	3	Oil Pump Bolt Nuts 1¼" Cge	Not shown	

# Oil Valve

Stock No.	No. per Car.		Plate No.	Price.
00308 C	1	Oil Valve Casting .....	17	.....
0369 C	1	Oil Valve Shut Off Stem .....	17	.....
00379 C	1	Oil Valve Shut Off Stem Wheel .....	17	.....
00460 A	1	Oil Valve Shut Off Gland .....	17	.....
00450 A	1	Oil Valve Shut Off Nut .....	17	.....
00371 C	2	Oil Valve Ball Checks 1/4" .....	17	.....
00380 A	2	Oil Valve Ball Checks Caps .....	17	.....
00380 1/4 C	1	Oil Valve Ball Checks Cap .....	17	.....
00380 1/2 A	3	Oil Valve Ball Checks Cap Gaskets .....	17	.....
0372 C	1	Oil Valve Valve .....	17	.....
0373 C	1	Oil Valve Spring .....	17	.....
	2	Oil Valve Support Bolts 1/4x3/4 Cge. ....	Not shown	.....
	2	Oil Valve Support Bolts Nuts 1/4 Cge. ....	Not shown	.....
0538 B	1	Oil Line Union End (1/8 Steel) .....	17	.....
0539 C	1	Oil Line Union End Nut (1/8 Steel) .....	17	.....
00944 E	1	Oil Line Nipple (Valve to Tee) .....	17	.....

## Oil Line to Cylinder

0538 B	1	Oil Pipe Union End 1/8 Steel Small Hole .....	17	.....
0539 C	1	Oil Pipe Union End Nut 1/8 Steel .....	17	.....
00042 E	1	Oil Pipe Long (To Valve) 1/4x8 1/4 Copper .....	17	.....
00308 C	1	Oil Valve .....	17	.....
0538 A	1	Oil Pipe Union End (1/8 Steel) .....	17	.....
0539 C	1	Oil Pipe Union End Nut (1/8 Steel) .....	17	.....
00055 E	1	Oil Pipe Valve (To Oil Ell) 1/8 Brass P. 33 1/4" .....	17	.....
00079 E	1	Oil Reducing Coupling 1/4x1/2 .....	17	.....
00485 E	1	Oil Ell (On Cylinder) .....	17	.....
0539 C	1	Oil Pipe Union Nut (1/8 Steel) .....	17	.....
00929 C	1	Oil Connection in Cylinder .....	8	.....

## Oil Line to Casing

0538 B	1	Union End 1/8 Steel .....	17	.....
0539 C	1	Union End Nut 1/8 Steel .....	17	.....
00940 E	1	Oil Pipe (Lug to Oil Conn. 484) 1/4" Copper Tube 29 1/4 .....	17	.....
0538 B	1	Oil Pipe Union End 1/8 Steel on pipe .....	17	.....
0539 C	1	Oil Pipe Union End Nut 1/8 Steel on pipe .....	17	.....
00484 E	1	Oil Pipe Connection to Case .....	17	.....
S0945 E	1	Oil Pipe Clip .....	17	.....

## By Pass Valve

00545 E	1	By Pass Valve .....	21	.....
00400 A	1	By Pass Valve Rod Gland .....	21	.....
00459 A	1	By Pass Valve Rod Gland Nut .....	21	.....
0546 E	1	By Pass Valve Rod .....	21	.....
395 E	1	By Pass Valve Rod Handle .....	21	.....
S0395 E	1	By Pass Valve Rod Flange .....	21	.....
0504 C	1	By Pass Valve Rod Washer .....	21	.....
S0546 E	1	By Pass Valve Rod Lock Washer .....	21	.....

## By Pass Valve—Continued

Stock No.		No. per Car.		Plate No.	Price.
00548	E	1	By Pass Valve Pipe (Valve to Ell) 12 $\frac{3}{4}$ x $\frac{1}{8}$ Brass .....	21	.....
00538	D	1	By Pass Valve Pipe Union Finished $\frac{1}{8}$ .....	21	.....
00539	A	1	By Pass Valve Pipe Union Nut $\frac{1}{8}$ .....	21	.....
0538	C	1	By Pass Valve Pipe Union Painted $\frac{1}{8}$ Steel.....	21	.....
0539	C	1	By Pass Valve Pipe Union Nut $\frac{1}{8}$ .....	21	.....
00498	C	1	By Pass Valve Pipe Ell .....	21	.....
00549	E	1	By Pass Valve Pipe (Ell to Upper Pump 36x $\frac{1}{8}$ Brass) .....	21	.....
0538	C	1	By Pass Valve Pipe Union ( $\frac{1}{8}$ Steel) .....	21	.....
0539	C	1	By Pass Valve Pipe Union ( $\frac{1}{8}$ Steel) .....	21	.....
S943	E	1	By Pass Valve Pipe Clip (on Dash) .....	21	.....
S394	C	1	By Pass Valve Rod Nut .....	21	.....
S00545 $\frac{1}{2}$	E	1	By Pass Valve Tank Nut .....	21	.....
00545 $\frac{1}{2}$	E	1	By Pass Valve Tank Lock Washer .....	21	.....
547	E	1	By Pass Valve Leather Washer .....	21	.....

## Steam Gauge

615	F	1	Steam Gauge 800 lbs. ....	19	.....
00538	E	1	Steam Gauge Union Ends $\frac{1}{8}$ .....	19	.....
00539	E	1	Steam Gauge Union Ends Nut .....	19	.....
00943	E	1	Steam Gauge Pipe (Gauge to Ell) 19 $\frac{1}{2}$ in. Long.	19	.....
0538	B	1	Steam Gauge Pipe Union End $\frac{1}{8}$ Steel Small Hole .....	19	.....
0539	C	1	Steam Gauge Pipe Union Nut $\frac{1}{8}$ Steel.....	19	.....
00498	C	1	Steam Gauge Pipe Ell .....	19	.....
00417 $\frac{1}{2}$	E	1	Steam Gage Pipe Nipple 1x $\frac{1}{8}$ in. ....	19	.....
00612	E	1	Steam Gauge Pipe Tee $\frac{1}{8}$ x $\frac{1}{8}$ x $\frac{1}{8}$ .....	19	.....
00941	E	1	Steam Gauge Pipe (Tee to Ell) .....	19	.....
0538	C	1	Steam Gauge Pipe Union End $\frac{1}{8}$ Steel.....	19	.....
00539	C	1	Steam Gauge Pipe Union Nut $\frac{1}{8}$ Steel.....	19	.....
00498	C	1	Steam Gauge Pipe Ell .....	19	.....
00935	E	1	Steam Gauge Pipe (Ell to W. Reg.) $\frac{1}{8}$ B.—P. 35	19	.....
0538	C	1	Steam Gauge Pipe Union End $\frac{1}{8}$ Steel.....	19	.....
0539	C	1	Steam Gauge Pipe Union Nut $\frac{1}{8}$ Steel.....	19	.....
S0935	E	1	Steam Gauge Pipe Union Clip .....	19	.....
S00616	E	3	$\frac{5}{8}$ -6 Brass Rd. Hd. Screws.....	19	.....

## Air Gauge

616	F	1	Air Gauge 80 lbs. ....	19	.....
00538	E	1	Air Gauge Union End $\frac{1}{8}$ .....	19	.....
00539	E	1	Air Gauge Union Nut $\frac{1}{8}$ .....	19	.....
00951	E	1	Air Gauge Pipe (To Tank Connection) $\frac{1}{8}$ Tubing 28 $\frac{1}{4}$ " .....	19	.....
0538	B	1	Air Gauge Pipe Union End $\frac{1}{8}$ Steel .....	19	.....
0539	C	1	Air Gauge Pipe Union End Nut $\frac{1}{8}$ Steel.....	19	.....
S0943	C	1	Air Gauge Pipe Clip .....	17	.....
00497	E	1	Air Pipe Connection to Gasoline Tank.....	19	.....
0538	C	1	Air Pipe Union End $\frac{1}{8}$ Steel.....	19	.....

## Air Guage—Continued

Stock No.	No. per Car.		Plate No.	Price.
0539 C	1	Air Pipe Union Nut $\frac{3}{8}$ " Steel	19	
00956 E	1	Air Pipe (Tank Conn. to Union) $\frac{1}{8}$ " Brass P....	19	
00538 $\frac{1}{2}$ B	1	Air Pipe Union End $\frac{1}{4}$ " Ground Female	19	
0539 C	1	Air Pipe Nut ( $\frac{3}{8}$ " Steel)	19	
00493 $\frac{1}{2}$ E	1	Air Pipe Nipple (2 $\frac{1}{2}$ " Union)	19	
00935 $\frac{1}{2}$ E	1	Air Pipe Check (Basselin)	19	
00934 E	1	Air Pipe Ell (To Check on Pump) $\frac{1}{4}$ " Brass 28"	19	
00936 $\frac{1}{2}$ E	1	Air Pipe Ell $\frac{3}{8}$ "x $\frac{1}{4}$ " Brass—Beaded	19	
00977 $\frac{1}{2}$ E	1	Air Pipe Union End $\frac{1}{4}$ " Brass	19	
00978 D	1	Air Pipe Union Nut $\frac{1}{4}$ " Brass	19	
0234 $\frac{1}{2}$ E	1	Air Pipe Clip	19	
S00616 E	3	Air Gauge Screws $\frac{5}{8}$ -6 Brass Rd. Hd.	19	

## Steering Stem

015 E	1	Steering Stem	21	
16 E	1	Steering Worm Bracket	21	
17 C	1	Steering Worm Bracket Cap	21	
	2	Steering Worm Bracket Bolts 3 $\frac{1}{2}$ "x16	Not shown	
	2	Steering Worm Bracket Nuts $\frac{3}{4}$ "	Not shown	
S016 C	6	Steering Worm Bracket Bolts	21	
0018 C	2	Steering Worm Bracket Bushings	21	
022 C	1	Steering Stem Head	21	
S022 C	1	Steering Stem Head Nut	21	
023 C	1	Steering Worm Segment	21	
023 $\frac{1}{2}$ C	2	Steering Worm Segment Thrust Washers	21	
0024 C	2	Steering Worm Adj. Bushings	21	
025 C	1	Steering Worm	21	
0099 C	1	Steering Worm Bracket Grease Cup	1	
0099 $\frac{1}{2}$ C	1	Steering Worm Bracket Grease Cup Cap	1	
013 F	1	Steering Stem Lever	21	
S013 C	1	Steering Stem Lever Bolt	21	
S055 C	1	Steering Stem Lever Bolt Nut	21	
21 E	1	Steering Wheel Rim	21	
0020 F	1	Steering Wheel Rim Spider	21	
S0020 $\frac{1}{2}$ E	3	Steering Wheel Rim Spider Screws	21	
S019 C	1	Steering Case Blind Screw	21	
0036 $\frac{1}{2}$ E	2	Foot Lever Shaft Bushings	21	

## Throttle

300 E	1	Throttle Casting	14	
304 E	1	Throttle Stem Lever	14	
00301 E	1	Throttle Stem Lever Friction Plate	14	
303 E	1	Throttle Stem	14	
S303 E	1	Throttle Stem Seat	14	
S303 $\frac{1}{2}$ E	1	Throttle Stem End	14	
S0304 E	1	Throttle Stem Nut	14	
00120 A	1	Throttle Stem Gland	14	
00121 A	1	Throttle Stem Adj. Nut	14	
00120 $\frac{1}{4}$ E	1	Throttle Stem Gland Washer	14	

## Throttle—Continued

Stock No.		No. per Car.		Plate No.	Price.
00309	E	1	Throttle Stem Stuffing Box Nut.....	14	.....
310	E	1	Throttle Friction Plate Arm.....	14	.....
S0310	E	1	Throttle Friction Plate Arm Screw.....	14	.....
00311	E	1	Throttle Stem Stuffing Box.....	14	.....
00311½	E	1	Throttle Stem Stuffing Box Gasket.....	14	.....
0312	E	1	Throttle Friction Plate Washer.....	14	.....
0313	E	1	Throttle Friction Plate Spring.....	14	.....
305	E	1	Throttle Wheel Rim.....	14	.....
S0306	F	1	Throttle Wheel Rim Stud.....	14	.....
00307	F	1	Throttle Wheel Rim Spider.....	14	.....
S0020½	E	3	Throttle Wheel Rim Spider Screws.....	14	.....
S0307	C	1	Throttle Wheel Rim Spider Taper Pin.....	14	.....
0308	E	1	Throttle Rod.....	14	.....
00308½	C	1	Throttle Rod Collar.....	14	.....
304	C	2	Throttle Rod Levers.....	14	.....
84	C	2	Throttle Rod Lever Rod Ends.....	14	.....
S081	A	2	Throttle Rod Levers Rod Ends Nuts.....	14	.....
S031½	C	2	Throttle Rod Levers Rod Ends Pins.....	14	.....
0319	E	1	Throttle Rod (Lever to Lever).....	14	.....
S0170	A	2	Throttle Rod Lever Taper Pins.....	14	.....
14	C	1	Throttle Stem Bearing.....	14	.....
0013½	E	1	Throttle Stem Bearing Bushing (Small).....	14	.....
0014½	E	1	Throttle Stem Bearing Bushing (Large).....	14	.....
S14	C	1	Throttle Stem Bearing Nut.....	14	.....
S019	F	1	Throttle Stem Bearing Lock Screws.....	14	.....
S0118	A	1	Throttle Stem Bearing Lock Screws Nut.....	14	.....
00309½	F	1	Throttle Rod Collar Washer (Small).....	14	.....

## Automatic Air Pump Shaft

0217	E	1	Air Pump Foot Plunger.....	19	.....
0217½	C	1	Air Pump Foot Plunger Plate.....	19	.....
00192	C	1	Air Pump Foot Plunger Guide.....	19	.....
½-3	F.H. Brass	3	Air Pump Foot Plunger Screws.....	Not shown	.....
0213	E	1	Air Pump Shaft.....	19	.....
215	C	1	Air Pump Shaft Lever.....	19	.....
S0170	A	1	Air Pump Shaft Lever Taper Pin.....	19	.....
216	E	1	Air Pump Shaft Pull Lever.....	19	.....
0216½	E	1	Air Pump Shaft Pull Lever Spring.....	19	.....
S0216½	E	1	Air Pump Shaft Pull Lever Spring Clip.....	Not shown	.....
S0217	E	1	Air Pump Pull Rod 3x½.....	19	.....
84	C	2	Air Pump Pull Rod Ends.....	19	.....
S081	A	2	Air Pump Pull Rod Ends Nuts.....	19	.....
S031½	C	2	Air Pump Pull Rod Ends Pins.....	19	.....
S0213	E	1	Air Pump Shaft Collar.....	19	.....
02214	E	3	Air Pump Shaft Brackets.....	19	.....

## Reverse Shaft

0179	E	1	Reverse Shaft.....	20	.....
180	F	1	Reverse Hand Lever.....	20	.....
0250½	C	1	Reverse Hand Lever Handle.....	20	.....

## Reverse Shaft—Continued

Stock No.	No. per Car.		Plate No.	Price.
0051	F	1	Reverse Hand Lever Handle Latch	20
S051	C	3	Reverse Hand Lever Handle Latch Pins	20
181	F	1	Reverse Hand Dog	20
S052	F	1	Reverse Hand Dog Pin	20
S052½	F	1	Reverse Hand Dog Pin	20
0182	E	1	Reverse Shaft Lever Latch Rod R. H.	20
0182½	E	1	Reverse Shaft Lever Latch Rod L. H.	20
S053	C	1	Reverse Hand Lever Latch Rod Turnbuckle	20
053½	C	1	Reverse Hand Lever Latch Rod Spring	20
S0180	C	1	Reverse Hand Lever Clamp Bolt	20
S081	A	1	Reverse Hand Lever Clamp Bolt Nut	20
178	E	1	Reverse Quadrant	20
S0178	E	1	Reverse Quadrant Bolt (Long)	20
S0178½	E	1	Reverse Quadrant Bolt (Short)	20
S081	A	2	Reverse Quadrant Bolt Nuts	20
0184½	E	1	Reverse Rod 39"	20
84	E	2	Reverse Rod Ends	20
S031½	C	2	Reverse Rod Ends Pins	20
S0157	C	2	Reverse Rod Ends Binder Screws 5/8-14-20	20
0183	E	1	Reverse Shaft Lever	20

### Hand Water Pumps

00200	C	1	Hand Water Pump Barrel	15
0201	C	1	Hand Water Pump Plunger	15
S00201	C	1	Hand Water Pump Plunger Collar	15
00201½	C	1	Hand Water Pump Plunger Tube	15
S0200	C	1	Hand Water Pump Plunger End	15
00120	B	1	Hand Water Pump Plunger Gland 1/4" Hole	15
00121	B	1	Hand Water Pump Plunger Adj. Nut 3/8" Hole	15
202	E	1	Hand Water Pump Plunger Knob	15
S00202	C	1	Hand Water Pump Plunger Knob Sleeve	15
00203	C	1	Hand Water Pump Plunger Valve	15
0212	A	1	Hand Water Pump Lock Nut	15
S0202½	E	1	Hand Water Pump Knob Screw	15
00336	F	1	Hand Water Pump Casting	15
S00325	C	2	Hand Water Pump Plugs	Not shown
00320	C	2	Hand Water Pump Ball Checks	15
S326	C	2	Hand Water Pump Ball Checks Seats	15
00327	C	2	Hand Water Pump Ball Checks Caps 3/4-20	15
00328	C	2	Hand Water Pump Ball Checks Gaskets	15

### Hand Air Pumps

0205	C	1	Hand Air Pump Barrel	14
00206	C	1	Hand Air Pump Head	14
00207	F	1	Hand Air Pump Foot	14
00208	C	1	Hand Air Pump Plunger	14
0209	C	1	Hand Air Pump Plunger Center	14
202	E	1	Hand Air Pump Plunger Knob	14
S00202	C	1	Hand Air Pump Plunger Knob Sleeve	14
S00209	C	1	Hand Air Pump Plunger End	14



## Hand Air Pumps—Continued

Stock No.	No. per Car.		Plate No.	Price.
0208½ C	1	Hand Air Pump Plunger Washers (Small).....	14	.....
0209½ C	1	Hand Air Pump Plunger Washers (Large) ....	14	.....
204¾ C	1	Hand Air Pump Plunger Leather (Small) .....	14	.....
204½ C	1	Hand Air Pump Plunger Leather (Large) .....	14	.....
0212 A	1	Hand Air Pump Lock Nuts .....	14	.....
00203 C	1	Hand Air Pump Valve .....	14	.....
00203½ E	1	Hand Air Pump Bottom Nipple 1¾x½ Brass....	14	.....
00417 A	1	Hand Air Pump Ell ½ Brass.....	14	.....
00203½ E	1	Hand Air Pump Bottom Nipple 1¾x½ Brass....	14	.....
00204 C	1	Hand Air Pump Check ¾ .....	14	.....
00952 E	1	Hand Air Pipe to Gas Tank Connection 9 2-8"....	14	.....
00539 A	1	Union Nut ¾ Brass.....	14	.....
00538 D	1	Union End ¾ Brass.....	14	.....
00484 C	1	Union Connection .....	14	.....

## Gasoline Line

00484 C	1	Gasoline Tank Connection .....	12	.....
00954 E	1	Gasoline Line Pipe Connection ¾ Brass 6¼" to Valve .....	12	.....
500 E	1	Gasoline Valve—Complete .....	17	.....
0538 A	1	Union End ¾ Steel .....	12	.....
00539 C	1	Union End Nut ¾ Brass .....	12	.....
00957 E	1	Pipe (Valve to Ground Union) ¾ Brass 39"....	12	.....
0538 A	1	Union End ¾ Steel .....	12	.....
00539 C	1	Union End Nut .....	12	.....
0538½ B	1	Gasoline Line Check Gasket .....	12	.....
00417½ E	1	Gasoline Line Nipple 2x½" .....	12	.....
00417 A	1	Gasoline Line Ell ½ .....	12	.....
00417½ E	1	Gasoline Line Nipple 1x½ .....	12	.....
00911¾ A	1	Gasoline Line Tee ½x¼x½ .....	12	.....
00910½ E	1	Gasoline Line Nipple 4¼x5½ (Gasoline Filter)..	12	.....
00911½ A	1	Gasoline Line Ell ½x½ Brass.....	12	.....
00417½ E	1	Gasoline Line Nipple ½x1" Brass.....	12	.....
00538 A	1	Union End ¾ Steel.....	12	.....
00538½ B	1	Ground Union End.....	12	.....
0539 C	1	Union End Nut.....	12	.....
00493 C	1	Nipple to Sub Burner Feed Valve.....	12	.....
401 E	1	Pipe Clip on Frame.....	12	.....
	1	Pipe Clip Screw ½-14-20.....	Not shown	.....
00499 A	1	Gasoline Line Wicking Clip .....	12	.....
419½ A	1	Gasoline Line Wicking .....	12	.....
418 A	1	Sub Burner Line Wicking Clip .....	12	.....
418½ A	1	Sub Burner Line Wicking .....	12	.....

## Gasoline Valve

00500 C	1	Gasoline Valve Casting .....	17	.....
0501 C	1	Gasoline Valve Stem .....	17	.....
395 C	1	Gasoline Valve Stem Wheel .....	17	.....
So.395 C	1	Gasoline Valve Stem Wheel Flange .....	17	.....

## Gasoline Valve—Continued

Stock No.		No. per Car.		Plate No.	Price.
S0394	C	1	Gasoline Valve Stem Nut .....	17	.....
0504	C	1	Gasoline Valve Stem Washer .....	17	.....
00400	A	1	Gasoline Valve Stem Gland .....	17	.....
00459	A	1	Gasoline Valve Stem Adj. Nut .....	17	.....
0501 1/2	E	1	Gasoline Valve Stem Locking Collar .....	17	.....
S0501	E	1	Gasoline Valve Stem Locking Collar Pin .....	Not shown	.....

## Gasoline Tank

218	E	1	Gasoline Tank .....	Not shown	.....
00222	C	1	Gasoline Tank Trunion Front .....	Not shown	.....
00223	C	1	Gasoline Tank Trunion Rear .....	Not shown	.....
00924	A	3	Gasoline Tank Try Cocks .....	17	.....
S0924	A	3	Gasoline Tank Try Cocks Stems .....	17	.....
S00924 1/2	A	3	Gasoline Tank Try Cocks Stems Collars .....	17	.....
00484	E	1	Gasoline Tank Connections .....	17	.....
00397	E	1	Gasoline Tank Air Connection to Power Pump .....	17	.....
00484	C	1	Gasoline Tank Air Connection from Hand Pump .....	17	.....
00560	A	1	Gasoline Tank Air Filling Hole Bracket .....	12	.....
00561	A	1	Gasoline Tank Air Filling Hole Cap .....	17	.....
00953	E	1	Air Pipe (in Tank) .....	17	.....
561 1/2	A	1	Filling Hole Cap Washer Fiber .....	17	.....
560 1/2	A	1	Filling Hole Cap Washer Rubber .....	17	.....
0223 1/2	E	1	Gasoline Tank Frame Clip .....	Not shown	.....
S0223 1/2	A	1	Gasoline Tank Frame Clip Screw .....	Not shown	.....
00963	E	1	Gasoline Tank Strainer .....	17	.....

## Main Burner

375	F	1	Main Burner Casting .....	16	.....
0376	F	1	Main Burner Pan .....	16	.....
0378	F	1	Main Burner Spreader .....	Not shown	.....
380	FF	1	Main Burner Mixing Tube (Large) .....	16	.....
577	A	4	Main Burner Clamps .....	16	.....
S0578	A	4	Main Burner Clamp Studs .....	16	.....
S0579	A	8	Main Burner Clamp Stud Nuts .....	16	.....

## Main Burner Bracket

0558	C	1	Main Burner Bracket Spindle Connection .....	19	.....
S0559	A	2	Main Burner Bracket Connecting Pins .....	19	.....
0559 1/2	A	4	Main Burner Bracket Connecting Pins Washers .....	19	.....
552	F	1	Main Burner Bracket Bracket .....	19	.....
S0553	C	1	Main Burner Bracket Bracket Spindle .....	19	.....
S555	A	2	Main Burner Bracket Bracket Spindle Gears .....	19	.....
S0555 1/2	A	4	Main Burner Bracket Bracket Spindle Gear Set Screws 1/8 x 1/2 .....	19	.....
S0394	A	1	Main Burner Bracket Bracket Spindle Nut .....	19	.....
551	C	1	Main Burner Bracket Bracket Spindle Wheel .....	19	.....
S00395	C	1	Main Burner Bracket Bracket Spindle Flange .....	19	.....
0550	E	1	Main Burner Bracket Rod .....	19	.....
550 1/2	C	1	Main Burner Bracket Rod Wheel .....	19	.....

## Main Burner Bracket—Continued

Stock No.		No. per Car.		Plate No.	Price.
00357	C	1	Main Burner Bracket Rod Wheel Flange .....	19	.....
S0358	A	1	Main Burner Bracket Rod Wheel Flange Screw .....	19	.....
		2	Main Burner Bracket Wood Screws 1-12 Rd. Hd. ....	Not shown	.....
		1	Main Burner Bracket Shimming Pad .....	Not shown	.....

## Sub Burner

00400	A	1	Sub Burner Vaporizer .....	11	.....
00401	F	1	Sub Burner Shell .....	11	.....
00402	A	1	Sub Burner Branch .....	11	.....
0403	F	1	Sub Burner Branch Pin Valve .....	11	.....
S00403	A	1	Sub Burner Branch Stuffing Box Nut .....	11	.....
S00404	A	1	Sub Burner Branch Stuffing Box Gland .....	11	.....
00404	F	1	Sub Burner Feed Pipe .....	11	.....
S0405	A	10	Sub Burner Vaporizer Screws 5-36 .....	11	.....
S0406	F	3	Sub Burner Shell Screws .....	11	.....
407	A	1	Sub Burner Cap .....	11	.....
00411	A	1	Sub Burner Feed Valve .....	11	.....
0412	A	2	Sub Burner Feed Valve Pin Valves .....	11	.....
S00404	A	2	Sub Burner Feed Valve Pin Valve Glands .....	11	.....
S00403	A	2	Sub Burner Feed Valve Pin Valve Nuts .....	11	.....
00401½	F	1	Sub Burner Shell Ell .....	11	.....
00416	F	1	Sub Burner Flush Pipe ¼" .....	11	.....
S00414	A	1	Sub Burner Flush Pipe End .....	11	.....
S00413	A	1	Sub Burner Flush Pipe End Nut .....	11	.....
00405	A	10	Sub Burner Vaporizer Gaskets .....	11	.....
00417	A	1	Sub Burner Feed Pipe Ell ¼" .....	11	.....
00415	C	1	Sub Burner Nipple 1x1" .....	11	.....
419	E	2	Sub Burner Nipple Wicking .....	11	.....
S0402	A	2	Sub Burner Branch Screws .....	11	.....
0416½	A	1	Sub Burner Flush Pipe Clip .....	Not shown	.....
420	F	1	Sub Burner Ventilator R. H. ....	11	.....
421	F	1	Sub Burner Ventilator L. H. ....	11	.....
S0420	F	3	Sub Burner Ventilator Screws .....	11	.....
S0407	F	2	Sub Burner Lighting Cap Screws .....	11	.....

## Vaporizer

531	F	1	Vaporizer Casting .....	11	.....
0532	F	1	Vaporizer Inlet Pipe .....	11	.....
0532½	F	1	Vaporizer Outlet Pipe .....	11	.....
0538	A	1	Vaporizer Union End ¼" .....	11	.....
0539	C	1	Vaporizer Union End Nut ¼" .....	11	.....
534	F	1	Vaporizer Support Post .....	11	.....
0535	C	1	Vaporizer End Support .....	11	.....
S0532	A	14	Vaporizer Screws .....	11	.....
00533	A	15	Vaporizer Screw Gaskets .....	11	.....
00536	F	1	Vaporizer Nozzle .....	11	.....
0537	E	1	Vaporizer Nozzle Cleaner .....	11	.....
00540	A	1	Vaporizer Nozzle Cleaner Washer .....	11	.....
S00403	A	1	Vaporizer Nozzle Cleaner Adj. Nut .....	11	.....

## Vaporizer—Continued

Stock No.		No. per Car.		Plate No.	Price.
S00404	A	1	Vaporizer Nozzle Cleaner Gland .....	11	.....
00536	FF	1	Vaporizer Nozzle .....	11	.....
00537	FF	1	Vaporizer Nozzle Cap .....	11	.....

### Thermostat

00425	E	1	Thermostat Casting .....	10	.....
0426	F	1	Thermostat Flange .....	10	.....
S00427	A	1	Thermostat Top Screw Cap .....	10	.....
S00428	C	1	Thermostat Plunger .....	10	.....
S00429	A	1	Thermostat Plunger Nut (Plain) .....	10	.....
S00430	A	1	Thermostat Plunger Nut (Collar) .....	10	.....
00431	A	1	Thermostat Top Screw Gasket .....	10	.....
0432	E	1	Thermostat Shut Off Valve .....	10	.....
S0554	A	1	Thermostat Shut Off Valve Head .....	10	.....
00433	A	1	Thermostat Shut Off Valve Stuffing Box Nut ..	10	.....
00434	A	1	Thermostat Shut Off Valve Stuffing Box Gland.	10	.....
00436	F	1	Thermostat Copper Tube .....	10	.....
437	F	1	Thermostat Regulator Rod .....	Not shown	.....
0438	A	1	Thermostat End Cap for Tube .....	10	.....
0439	A	1	Thermostat Flange Plug .....	Not shown	.....
S0301	A	4	Thermostat Flange Screws .....	10	.....
440	A	1	Thermostat Regulator Rod Lever .....	10	.....
00441	A	1	Thermostat Regulator Rod Lever Pin .....	10	.....
S0442	A	2	Thermostat Screw Plugs .....	10	.....
S00432	A	1	Thermostat Shut Off Valve Washer .....	10	.....
S00426	A	1	Thermostat Flange Gasket .....	10	.....
S0425	E	1	Thermo Shut Off Screw Lock Nut .....	10	.....

### Generator

0907	E	1	Generator Coil No. 1 .....	16	.....
0908	E	1	Generator Coil No. 2 .....	16	.....
0909	E	1	Generator Coil No. 3 .....	16	.....
0910	E	1	Generator Coil No. 4 .....	16	.....
0911	E	1	Generator Coil No. 5 .....	16	.....
0912	E	1	Generator Coil No. 6 .....	16	.....
0913	E	1	Generator Coil No. 7 .....	16	.....
0914	E	1	Generator Coil No. 8 .....	16	.....
0915	E	1	Generator Coil No. 9 .....	16	.....
0916	E	1	Generator Coil No. 10 .....	16	.....
0917	E	1	Generator Coil No. 11 .....	16	.....
0918	E	6	Generator Nipples 8"x14" .....	16	.....
0920	A	8	Generator Ells R. H. 1/4" .....	10	.....
0921	A	7	Generator Ells R. & L. 1/4" .....	10	.....
0922	A	4	Generator Couplings 1/4" .....	16	.....
0901	E	1	Generator Spreaders Single Narrow .....	16	.....
0901 1/4	E	1	Generator Spreaders Double Narrow .....	16	.....
0901 1/2	E	1	Generator Spreaders Double Wide .....	16	.....
0901 3/4	E	1	Generator Spreaders Double Narrow .....	16	.....
580	F	1	Generator Coil Support Bracket .....	16	.....
S035	A	4	Generator Coil Support Bracket Nuts .....	16	.....

## Generator—Continued

Stock No.		No. per Car.		Plate No.	Price.
0902	E	4	Generator Coil Supports (Long) .....	16	.....
573	F	1	Generator Casing Inner .....	Not shown	.....
573½	F	1	Generator Casing Outer .....	Not shown	.....
0960	F	1	Generator Casing Door—Upper .....	16	.....
0961	F	1	Generator Casing Door—Lower .....	16	.....
00573¼	F	2	Generator Casing Door Guides .....	Not shown	.....
574	F	1	Generator Casing Lining .....	Not shown	.....
575	F	1	Generator Casing Ring—Upper .....	16	.....
576	F	1	Generator Casing Ring—Lower .....	16	.....
00608	F	4	Generator Casing Lugs .....	12	.....
S0608	F	2	Generator Casing Lug Rivets .....	Not shown	.....
2¼x¼					
Step		4	Generator Casing Lug Bolts .....	Not shown	.....
5-16		4	Generator Casing Lug Bolt Nuts .....	Not shown	.....
611	F	2	Generator Casing Side Support—Lower.....	12	.....
609	F	1	Generator Casing Front Support—Lower.....	12	.....
610	F	1	Generator Outer Casing Front Support Lug .....	12	.....
2¾x¾		1	Generator Outer Casing Front Support Lug		
			Mach. Bolt .....	Not shown	.....
¾		1	Generator Outer Casing Front Support Lug		
			Mach. Bolt Nut .....	Not shown	.....
611½	F	1	Generator Casing Support Rear .....	123	.....
1-24-16					
Rd. Hd.		4	Generator Casing Support Screws Mach. Steel..	Not shown	.....
¾ Nat.		4	Generator Casing Support Screw Lock Washers..	Not shown	.....
510	F	1	Generator Casing Front Flue .....	Not shown	.....
510½	F	1	Generator Casing Front Flue Thermo Hood.....	Not shown	.....
00606	F	3	Generator Casing Front Flue Thermo Hood		
			Lugs .....	Not shown	.....
¼-12-24		3	Generator Casing Front Flue Thermo Hood		
			Lug Screws .....	Not shown	.....
511½	F	1	Generator Casing Rear Flue .....	Not shown	.....
971	F	1	Generator Casing Rear Flue Asbestos Pad.....	Not shown	.....
970	F	1	Generator Casing Top Asbestos Pad.....	Not shown	.....
4¾x¾		1	Generator Casing Rear Support Bolt—Mach. ...	Not shown	.....
¾		1	Generator Casing Rear Support Bolt—Mach. Nut		
661	F	1	Boiler Casing Support Wedge R. H.....	Not shown	.....
00582	F	1	Generator Casing Door Flange .....	Not shown	.....
00583	F	1	Generator Casing Thermo Flange .....	Not shown	.....
662	F	1	Boiler Casing Support L. H. ....	12	.....
663	F	2	Boiler Casing Wedge Supports .....	Not shown	.....

## Lower Branch

0479½	E	1	Generator Superheating Tube .....	12	.....
0479	E	1	Generator Superheating Tee R. H. ....	12	.....
0478	E	1	Generator Superheating Tee L. H. ....	12	.....
0478½	A	1	Generator Superheating Plug .....	12	.....

## Steam Line

Stock No.	No. per Car.		Plate No.	Price.
0508 C	1	Down Pipe (Thermo Tee to Union Ell).....	18	.....
0509 C	1	Down Pipe Nut $\frac{3}{8}$ Steel.....	18	.....
475 C	1	Union Ell $\frac{3}{8}$ Steel.....	18	.....
0948 E	1	Steam Pipe 1st .....	18	.....
0476 E	1	Steam Riser .....	18	.....
0947 $\frac{1}{2}$ E	1	Steam Riser Nipple 1 $\frac{1}{2}$ x $\frac{1}{4}$ .....	18	.....
00976 F	1	Steam Blow Off Valve .....	18	.....
00975 $\frac{1}{2}$ E	1	Steam Blow Off Valve Nipple 1x $\frac{1}{4}$ .....	18	.....
S0476 C	1	Steam Riser Head .....	18	.....
0509 C	1	Union Nut ( $\frac{3}{8}$ Steel Union).....	18	.....
0329 A	1	Union End ( $\frac{3}{8}$ Steel) .....	15	.....
0947 E	1	Steam Pipe 2nd ( $\frac{3}{8}$ Steel).....	18	.....
477 C	1	Steam Line Connection .....	18	.....
0508 $\frac{1}{2}$ C	1	Steam Line Connection to Throttle.....	18	.....
509 C	1	Union Nut ( $\frac{3}{8}$ Steel).....	18	.....
0947 $\frac{1}{2}$ E	1	Nipple 1 $\frac{1}{2}$ x $\frac{1}{4}$ .....	18	.....
00945 F	1	Safety Valve .....	18	.....
0949 C	1	Steam Pipe (Throttle to Engine) $\frac{3}{8}$ ".....	18	.....
0320 A	2	Union Ends $\frac{3}{8}$ Steel.....	18	.....
0509 C	2	Union Ends Nuts Steel .....	18	.....
00048 $\frac{1}{2}$ E	30	Lagging Bands .....	18	.....

## Water Line

906 E	1	Hose (Strainer to Upper Pump) $\frac{5}{8}$ x $9\frac{5}{8}$ .....	18	.....
00482 A	1	Hose Union End (Brass Spec) .....	18	.....
00978 D	1	Hose Union End Nut $\frac{1}{4}$ Brass .....	18	.....
00978 D	1	Hose Union End Nut $\frac{1}{4}$ Brass .....	18	.....
00977 $\frac{1}{2}$ E	1	Union End $\frac{1}{4}$ Brass Spec.....	18	.....
00486 E	1	Water Line Tee .....	18	.....
00978 D	1	Union End Nut $\frac{1}{4}$ .....	18	.....
00977 $\frac{1}{2}$ E	1	Union End $\frac{1}{4}$ Brass Spec.....	18	.....
0980 C	1	Water Line Tee $\frac{3}{8}$ x $\frac{3}{8}$ x $\frac{3}{8}$ .....	18	.....
00812 F	1	Spring Water Cushion Casting .....	18	.....
00813 F	1	Spring Water Cushion Inner Chamber.....	18	.....
0814 F	1	Spring Water Cushion Spring .....	18	.....
815 F	1	Spring Water Cushion Inner Washer—Leather..	18	.....
00816 F	1	Spring Water Cushion Inner Lock Washer—Brass	18	.....
00817 F	1	Spring Water Cushion Cap .....	18	.....
00818 F	1	Spring Water Cushion Pipe 14 $\frac{1}{8}$ x $\frac{3}{8}$ Brass.....	18	.....
00474 F	1	Pressure Hose Clamp Connection .....	18	.....
00474 $\frac{1}{2}$ E	1	Pressure Hose Clamp Connection Stud .....	18	.....
S0474 E	1	Pressure Hose Clamp Connection Stud Washer $\frac{1}{8}$ Natl.....	18	.....
S081 A	1	Pressure Hose Connection Stud Nut.....	18	.....
00938 E	1	Pressure Pipe Complete (Hose to Hand Pump) 19 $\frac{3}{4}$ x $\frac{3}{8}$ Brass .....	18	.....
00329 C	2	Pressure Pipe Union Ends $\frac{3}{8}$ Brass.....	18	.....
00330 C	2	Pressure Pipe Union Ends Nuts $\frac{3}{8}$ Brass.....	18	.....
0036 F	1	Water Pipe (Hand Pump to Tee) $\frac{1}{4}$ x1 $\frac{1}{4}$ .....	18	.....

## Water Line—Continued

Stock No.	No. per Car.		Plate No.	Price.
0977 C	1	Water Pipe Union End $\frac{1}{4}$ Steel .....	18	.....
00977 D	1	Water Pipe Union End $\frac{1}{4}$ Brass .....	18	.....
00978 D	2	Water Pipe Union Nuts $\frac{1}{4}$ Brass .....	18	.....
481 C	1	Water Pipe Tee .....	18	.....
0046 F	1	Water Pipe to Generator Steel Tubing $\frac{1}{4} \times 12 \frac{1}{4}$ .....	18	.....
00480 C	1	Water Pipe Union Ell .....	18	.....
00978 D	1	Water Pipe Union Nut Brass $\frac{1}{4}$ .....	18	.....
0959 C	1	Water Pipe Relief Pipe (Tee to Valve) $\frac{1}{4} \times 4$ .....	18	.....
00975 E	1	Blow Off Valve $\frac{1}{4}$ Globe .....	18	.....
00975 $\frac{1}{2}$ E	1	Blow Off Valve Nipple $\frac{1}{4} \times 1$ .....	18	.....
904 E	1	Hose Cond. Pump to Tank $\frac{1}{2} \times 31$ .....	18	.....
00977 $\frac{1}{2}$ C	1	Hose Nipple Union $\frac{1}{4}$ .....	18	.....
00978 D	1	Hose Nipple Union Nut $\frac{1}{4}$ .....	18	.....
00977 $\frac{1}{2}$ A	1	House Nipple Ground End Female $\frac{1}{4}$ .....	18	.....
00950 $\frac{1}{4}$ E	1	Nipple $\frac{1}{4} \times 1 \frac{1}{4}$ Brass .....	18	.....
00977 $\frac{1}{2}$ C	1	Union End $\frac{1}{4}$ Brass Spec. ....	18	.....
00978 D	1	Union End Nut $\frac{1}{4}$ .....	18	.....
00340 FF	1	Condenser Pump .....	8	.....
903 E	1	Hose Condenser to Pump .....	18	.....
00977 $\frac{1}{2}$ C	1	Union End $\frac{1}{4}$ Brass Spec. ....	18	.....
00978 D	1	Union End Nut $\frac{1}{4}$ .....	18	.....
00980 E	1	Hose Nipple .....	18	.....
00449 $\frac{1}{2}$ E	1	$\frac{1}{4}$ Street Ell .....	18	.....
00449 C	1	$\frac{1}{4}$ Pet Cock .....	18	.....
0958 E	1	Water Line Pipe (Pump to Pump) .....	11	.....
00977 D	2	Union Ends $\frac{3}{8}$ Brass .....	11	.....
00978 D	2	Union Ends $\frac{3}{8}$ Steel Union .....	11	.....

## Brake Shaft

038 F	1	Brake Shaft .....	Not shown	.....
41 F	1	Brake Shaft Lever .....	20	.....
50 F	1	Brake Shaft Hand Lever .....	20	.....
0050 $\frac{1}{2}$ C	1	Brake Shaft Hand Lever Handle .....	20	.....
0051 F	1	Brake Shaft Hand Lever Latch .....	20	.....
S051 F	2	Brake Shaft Hand Lever Latch Pins .....	20	.....
52 F	1	Brake Shaft Hand Lever Dog .....	20	.....
S052 C	1	Brake Shaft Hand Lever Latch Dog Pin .....	20	.....
S052 $\frac{1}{2}$ F	1	Brake Shaft Hand Lever Latch Dog Rod Pin .....	20	.....
053 C	1	Brake Shaft Hand Dog Latch Rod R. H. ....	20	.....
053 $\frac{1}{4}$ C	1	Brake Shaft Hand Dog Latch Rod L. H. ....	20	.....
S053 C	1	Brake Shaft Hand Dog Latch Turnbuckle .....	20	.....
S0180 C	1	Brake Shaft Hand Lever Clamp Bolt .....	20	.....
S081 A	1	Brake Shaft Hand Lever Clamp Bolt Nut .....	20	.....
178 $\frac{1}{2}$ E	1	Brake Quadrant .....	20	.....
0171 $\frac{1}{4}$ E	1	Brake Shaft Distance Tube .....	Not shown	.....
053 $\frac{1}{2}$ C	1	Hand Lever Latch Rod Spring .....	20	.....
081 F	1	Brake Cable .....	5	.....
84 F	2	Brake Cable Ends .....	5	.....
S031 $\frac{1}{2}$ F	2	Brake Cable End Pins .....	5	.....

## Brake Shaft—Continued

31

Stock No.	No. per Car.		Plate No.	Price.
So168 C	4	Brake Cable End Binder Screws $\frac{3}{8}$ -14-20	5	
o81 $\frac{1}{2}$ F	2	Brake Cable Guides	5	
So81 A	2	Brake Cable Guide Nuts	5	

### Change Gear Shaft

o179 $\frac{1}{2}$ E	1	Change Gear Shaft	20	
o180 $\frac{3}{4}$ E	1	Change Gear Shaft Lever	20	
180 $\frac{1}{2}$ F	1	Change Gear Hand Lever	20	
o050 $\frac{1}{2}$ C	1	Change Gear Hand Lever Handle	20	
So180 C	1	Change Gear Hand Lever Clamp Bolt	20	
So81 A	1	Change Gear Hand Lever Clamp Bolt Nut	20	
178 $\frac{3}{4}$ E	1	Change Gear Quadrant	20	
o42 F	1	Change Gear Pull Rod	20	
84 E	2	Change Gear Pull Rod End Front	20	
84 $\frac{1}{2}$ E	2	Change Gear Pull Rod End Rear	20	
So31 $\frac{1}{2}$ C	2	Change Gear Pull Rod End Pins	20	
	2	Change Gear Pull Rod End Screws $\frac{3}{8}$ -12-24	Not shown	

### Mud Guard (Front)

o278 E	1	Front Mud Guard R. H.	Not shown	
o279 E	1	Front Mud Guard L. H.	Not shown	
o280 E	1	Front Mud Guard Iron—Upper—R. H.	13	
o280 $\frac{1}{2}$ E	1	Front Mud Guard Iron—Upper—L. H.	13	
o281 E	1	Front Mud Guard Iron—Lower—R. H.	13	
o281 $\frac{1}{2}$ E	1	Front Mud Guard Iron—Lower—L. H.	13	
So35 A	4	Front Mud Guard Nuts $\frac{1}{2}$ -13	13	
So279 E	18	Front Mud Guard Rivets $\frac{3}{4}$ x $\frac{7}{8}$	Not shown	
o278 $\frac{1}{2}$ E	2	Front Mud Guard Flaps	Not shown	
o279 $\frac{1}{2}$ E	12	Front Mud Guard Flap Tubular Rivets	13	
o281 $\frac{3}{4}$ E	4	Front Mud Guard Iron Washers $\frac{1}{2}$	13	

### Mud Guard (Rear)

o284 F	1	Rear Mud Guard R. H.	Not shown	
o282 $\frac{1}{2}$ F	1	Rear Mud Guard L. H.	Not shown	
703 F	1	Rear Mud Guard Iron—Upper R. H.	13	
704 F	1	Rear Mud Guard Iron—Upper L. H.	13	
o283 F	1	Rear Mud Guard Iron—Lower R. H.	13	
o283 $\frac{1}{2}$ F	1	Rear Mud Guard Iron—Lower L. H.	13	
So279 E	6	Rear Mud Guard Iron Rivets $\frac{3}{4}$ -13	Not shown	
So35 A	4	Rear Mud Guard Iron Nuts $\frac{1}{2}$ -13	13	
So243 E	4	Rear Mud Guard Iron Upper Screws 1- $\frac{1}{2}$ F. H.		
		Annld.	13	
So35 A	4	Rear Mud Guard Iron Upper Nuts $\frac{1}{2}$ -12	13	
o281 $\frac{3}{4}$ E	4	Rear Mud Guard Iron Upper Washers $\frac{1}{2}$	13	
704 $\frac{1}{2}$ F	6	Rear Mud Guard Distance Tubes	13	
o385 E	6	Rear Mud Guard Iron Upper Screws 2"-12 F. H.	13	
So703 F	2	Rear Mud Guard Iron Upper Bolts	13	
So81 A	2	Rear Mud Guard Iron Upper Bolt Nuts	13	



## Lamp Brackets

Stock No.	No. per Car.		Plate No.	Price.
00270	F	1	Dash Lamp Bracket R. H. ....	13
00270½	F	1	Dash Lamp Bracket L. H. ....	13
S0270	E	2	Dash Lamp Bracket Bolts ....	13
S00296	C	4	Dash Lamp Bracket Bolt Nuts ....	13
00271	F	1	Rear Lamp Bracket ....	13
1¼-14		3	Rear Lamp Bracket Screws (F. Hd. Wood) ...	13

## Gas Lamp Brackets

00257	E	1	Gas Lamp Bracket ....	13
00257½	F	2	Gas Lamp Bracket Braces ....	13
S0195	C	2	Gas Lamp Bracket Brace Bolts ....	13
S081	A	2	Gas Lamp Bracket Brace Bolt Nuts ....	13
0259	E	2	Gas Lamp Bracket Bolts ....	13
S0259	C	4	Gas Lamp Bracket Bolt Nuts ....	13
00258	C	2	Gas Lamp Bracket Clamps ....	13

## Tire Holder

00655	F	1	Tire Holder Front Bracket ....	13
S0655	F	1	Tire Holder Front Bracket Set Screw ....	13
658	F	1	Tire Holder Front Bracket Strap ....	13
00657	F	1	Tire Holder Rear Bracket ....	13
S0243	C	2	Tire Holder Rear Bracket Screws 1X12 F. H. Annld. ....	Not shown
2-¼				
Stove		2	Tire Holder Rear Bracket Bolts ....	Not shown
¼		2	Tire Holder Rear Bracket Nuts ....	Not shown
658	F	1	Tire Holder Rear Bracket Strap ....	13
00656	F	1	Tire Holder Step Bracket ....	13
1¼-¼		2	Tire Holder Step Bracket Bolts ....	Not shown
Stove				
658	F	1	Tire Holder Step Bracket Strap ....	13
00656½	F	1	Tire Holder Step Bracket Double ....	13
659	F	1	Tire Cover ....	Not shown
659½	F	2	Tire Cover Laces ....	Not shown

## Portfolio

1086	F	1	Portfolio ....	Not shown
1086½	F	4	Portfolio Straps ....	Not shown
1088	F	5	Portfolio Strap Buckles ....	Not shown

## Seat Covers

1155	F	1	Front Seat Cover ....	Not shown
1156	F	1	Rear Seat Cover ....	Not shown
1159	F	1	Rear Cushion Cover ....	Not shown
1161	F	1	Front Cushion Cover R. H. ....	Not shown
1162	F	1	Front Cushion Cover L. H. ....	Not shown
1163	F	1	Generator Cushion Cover ....	Not shown
1164	F	1	Door Cover R. H. ....	Not shown
1165	F	1	Door Cover L. H. ....	Not shown

## Piping for Lamps

33

Stock No.	No. per Car.		Plate No.	Price.
00984	F	1	L. H. Pipe to Tank 3"-3"x $\frac{1}{4}$	Not shown
00986	E	1	L. H. Pipe Tee $\frac{1}{4}$	Not shown
00987	E	1	L. H. Pipe (To Bracket) 40 $\frac{1}{2}$ x $\frac{1}{4}$	Not shown
00988	E	1	R. H. Pipe (To Union) 12x $\frac{1}{4}$	Not shown
00989	E	1	Union $\frac{1}{4}$ x $\frac{3}{4}$	Not shown
00990	E	1	R. H. Pipe (To Bracket) 55 $\frac{3}{4}$ x $\frac{1}{4}$	Not shown
992	E	2	Rubber Tubes to Lamps 8 $\frac{1}{2}$ "	Not shown
S0943	E	7	Pipe Clips	Not shown
$\frac{1}{2}$ -3		7	Pipe Clip Screws F. Hd. Brass	Not shown
00985	E	1	L. H. Pipe on Dash 13 $\frac{1}{2}$ x $\frac{1}{4}$	Not shown
00986	E	1	L. H. Pipe Tee $\frac{1}{4}$	Not shown
00987	E	1	L. H. Pipe (To Bracket) 40 $\frac{1}{2}$ x $\frac{1}{4}$	Not shown
00988	E	1	Pipe to R. H. Union 12x $\frac{1}{4}$	Not shown
00989	E	1	Union $\frac{1}{4}$ x $\frac{3}{4}$	Not shown
00990	E	1	R. H. Pipe to Bracket 55 $\frac{3}{4}$ x $\frac{1}{4}$	Not shown
991	E	2	Rubbers on Generator 5	Not shown
992	E	2	Rubbers to Lamps 8 $\frac{1}{2}$	Not shown
S0943	E	7	Pipe Clips	Not shown
		7	Pipe Clip Screws $\frac{1}{2}$ No. 3	Not shown

## Lamps

001100	F	1	Favorite Side Lamp R. H. Hamm Lamp	Not shown
001100 $\frac{1}{2}$	F	1	Favorite Side Lamp L. H. Hamm Lamp	Not shown
001105	F	1	Vigilant Rear Lamp	Not shown
001101	F	1	Favorite Side Lamp Door R. H.	Not shown
001101 $\frac{1}{2}$	F	1	Favorite Side Lamp Door L. H.	Not shown
001106	F	1	Vigilant Rear Lamp Door	Not shown
1102	F	2	Favorite Side Lamp Glasses	Not shown
001103	F	2	Favorite Side Lamp Founts	Not shown
001108	F	1	Vigilant Rear Lamp Founts	Not shown
1107	F	1	Vigilant Rear Lamp Glass	Not shown
S001108	E	3	Lamp Bracket Set Screws	Not shown
001115	F	1	683 Parabolens Lamp R. H.	Not shown
001115 $\frac{1}{2}$	F	1	683 Parabolens Lamp L. H.	Not shown
001116	F	2	683 Parabolens Lamp Door	Not shown
1117	F	2	683 Parabolens Lamp Door Glass	Not shown
001120	F	1	657 Lens Mirror Lamp R. H.	Not shown
001121	F	1	657 Lens Mirror Lamp L. H.	Not shown
001122	F	2	657 Lens Mirror Lamp Doors	Not shown
1123	F	2	657 Lens Mirror Lamp Door Glasses	Not shown
001135	F	1	Prestolyte Tank	Not shown
001130	E	1	Autolite Generator	Not shown
001131	E	1	Autolite Generator Gas Bag	Not shown
001133	E	1	Solar Generator	Not shown

## Horn

00825	E	1	Horn	Not shown
00826	E	1	Horn Screen	Not shown
827	E	1	Horn Bulb	Not shown

## Horn—Continued

Stock No.	No. per Car.		Plate No.	Price.
S00828	E	2	Horn Screws $\frac{7}{8}$ x8 R. H. Brass	Not shown
S00827	E	4	Horn Screws $\frac{1}{2}$ -12-24	Not shown
00827 $\frac{1}{2}$	E	8	Horn Screw Nuts 12x24 Hex.	Not shown
00828	E	1	Horn Tubes	Not shown
00820	E	1	Horn Reed	Not shown

## Luggage Carrier

0672 $\frac{1}{2}$	F	1	Luggage Carrier Frame	22	
0673 $\frac{1}{2}$	F	1	Luggage Carrier Frame (Small)	22	
0675	F	1	Luggage Carrier Joint—Upper R. H.	22	
0675 $\frac{1}{2}$	F	1	Luggage Carrier Joint—Lower R. H.	22	
S0675	F	2	Luggage Carrier Joint Rivets	22	
671	F	2	Luggage Carrier Joint Hinges—Upper	22	
S0671	F	2	Luggage Carrier Joint Hinge Pins $1\frac{1}{4}$ x $\frac{1}{8}$	22	
S0243	C	4	Luggage Carrier Joint Hinge Screws 1-12 F. H.		
			Annld.	22	
673	F	2	Luggage Carrier Joint Hinges Lower	22	
S0671	F	2	Luggage Carrier Joint Hinge Pins	22	
672	F	2	Luggage Carrier Frame Hinges Female	22	
672 $\frac{1}{2}$	F	1	Luggage Carrier Frame Hinges Male	22	
S0672	F	2	Luggage Carrier Frame Hinge Pins	22	
685	F	2	Luggage Carrier Frame Putman Loops	22	
686	F	2	Luggage Carrier Frame Straps	22	
671 $\frac{1}{2}$	F	2	Luggage Carrier Stop Hinges (Body)	22	
674	F	2	Luggage Carrier Stop Hinges (Frame)	22	
2 $\frac{1}{2}$ - $\frac{1}{8}$					
North		2	Luggage Carrier Stop Hinge Bolts	Not shown	
S0243	C	2	Luggage Carrier Stop Hinge Screws 1-12-F. Hd.		
			Annld.	22	
S0670	F	2	Luggage Carrier Stop Hinge Pins $1\frac{1}{4}$ x $\frac{1}{8}$	22	
670	F	2	Luggage Carrier Stops	22	
00687	F	2	Luggage Carrier Body Plates	22	
$\frac{3}{4}$ -8		2	Luggage Carrier Wood Screws F. H. Brass	Not shown	

## Starting Shaft

191	E	1	Starting Lever	22	
0190	E	1	Starting Lever Rod 6"	22	
185	C	2	Starting Lever Rod Ends	8	
S0185	C	2	Starting Lever Rod End Blocks	8	
S0184	C	2	Starting Lever Rod End Pins	8	
S052	C	2	Starting Lever Rod End Pins	8	
S081	A	2	Starting Lever Rod End Pin Nuts	8	
0186	E	1	Starting Shaft 23-7 $\frac{1}{8}$ "	22	
S00186	C	2	Starting Shaft End Bushings	22	
188	C	2	Starting Shaft Levers	22	
077	E	1	Engine Starting Rod 18"	22	
185	C	2	Engine Starting Rod Ends	8	
S081	A	2	Engine Starting Rod End Nuts	8	
S0185	C	2	Engine Starting Rod End Blocks	8	

## Starting Shaft—Continued

35

Stock No.		No. per Car.		Plate No.	Price
S0184	C	2	Engine Starting Rod End Pins .....	8	.....
S052	C	2	Engine Starting Rod End Pins .....	8	.....
078	C	1	Engine Starting Spring .....	7	.....

### Driving Shaft

069	F	1	Driving Shaft .....	22	.....
073	F	1	Driving Shaft Toggle .....	22	.....
S072	C	1	Driving Shaft Toggle Dowell Pin .....	22	.....
072	F	1	Driving Shaft Universal Joint Head .....	22	.....
S072	C	1	Driving Shaft Universal Joint Head Dowell Pin .....	22	.....
074½	E	1	Driving Shaft Joint Case Cover .....	22	.....
074¼	E	1	Driving Shaft Joint Case Cover Ring .....	22	.....
07½	F	1	Front Toggle Boot .....	22	.....

### Tools

0881	C	1	Packing Fork .....	23	.....
0882	C	1	Tightener .....	23	.....
0883	C	1	Drill B .....	23	.....
0884	C	1	Drill No. 36 .....	23	.....
885	C	1	Dog .....	23	.....
886	E	1	Hub Wrench .....	23	.....
0887	C	1	Grease Injector .....	23	.....
888	C	1	Canister .....	23	.....
0889	E	1	Trimo Wrench .....	23	.....
0890	E	1	Bicycle Wrench .....	23	.....
0891	E	1	Auto 8" Wrench .....	23	.....
0892	C	1	File .....	23	.....
893	C	1	File Handle .....	23	.....
0894	C	1	Pair Pliers .....	23	.....
0895	E	1	4" Screw Driver .....	23	.....
0896	E	1	6" Screw Driver .....	23	.....
897	E	1	Tool Case .....	Not shown	.....
0899	C	1	Pilot Light Cleaner .....	23	.....

### Tool Box

875	F	1	Tool Box .....	Not shown	.....
876	F	1	Tool Box Partition .....	Not shown	.....
876½	F	1	Tool Box Tray .....	Not shown	.....
877	F	1	Tool Box Cover .....	Not shown	.....
00878	E	2	Tool Box Hinges .....	23	.....
S00878	E	12	Tool Box Hinge Rivets .....	23	.....
00878½	E	1	Tool Box Hasp .....	23	.....
00879	E	1	Tool Box Hasp Catch .....	23	.....
00880	E	1	Tool Box Pad Lock .....	23	.....
0880½	E	2	Tool Box Pad Lock Keys .....	23	.....
866	F	1	Tool Box Mat—Rubber .....	23	.....
867	F	1	Tool Box Mat Long Moulding .....	23	.....
867¼	F	1	Tool Box Mat Short Moulding .....	23	.....
867½	F	1	Tool Box Corner Moulding .....	23	.....
00864	F	1	Runabout Cover Hinge .....	23	.....
00865	F	1	Runabout Cover Hinge Catch .....	23	.....

## Body

Stock No.		No. per Car.		Plate No.	Price.
800	F	1	Body and Rear Seat .....	Not shown	.....
237	F	1	Side Door R. H. ....	Not shown	.....
237½	F	1	Side Door L. H. ....	Not shown	.....
00856	F	1	Side Door Hinge—Upper R. H. ....	23	.....
00856½	F	1	Side Door Hinge—Upper L. H. ....	23	.....
00855	F	1	Side Door Hinge—Lower R. H. ....	23	.....
00855½	F	1	Side Door Hinge—Lower L. H. ....	23	.....
S0855	F	24	Side Door Hinge Screws (1½-12 Brt.) .....	Not shown	.....
00285	F	2	Side Door Handles (Outside) .....	23	.....
00285½	F	2	Side Door Handle Ferrule .....	23	.....
00286	F	2	Side Door Handles (Inside) .....	23	.....
S00286	F	2	Side Door Handle Nuts (Acorn) .....	23	.....
0858	F	2	Side Door Lock and Catch R. H. ....	23	.....
0858½	F	2	Side Door Lock and Catch L. H. ....	23	.....
S0858	F	14	Side Door Lock Screws ¾-10 (F. Hd. Brt.)....	Not shown	.....
0859	F	2	Side Door Lock and Catch Strikes R. H. ....	23	.....
0859½	F	2	Side Door Lock and Catch Strikes L. H. ....	23	.....
S0858	F	8	Side Door Lock and Catch Strike Screws ¾-10 (Ft. Hd. Brt.) .....	Not shown	.....
850	F	2	Side Door Checks .....	Not shown	.....
00668	F	4	Side Door Check Loops .....	23	.....
S00805	F	8	Side Door Loop Screws 1¼-10 Brass.....	Not shown	.....
278½	F	1	Rear Heel Board .....	Not shown	.....
00288½	F	1	Rear Heel Board Brass Rim .....	Not shown	.....
S0288	F	13	Rear Heel Board Brass Rim Screws (¾-8) F. H. Brt.) .....	Not shown	.....
00288	F	2	Rear Heel Board Brass Catches .....	23	.....
S00810	C	12	Rear Heel Board Brass Screws (½-5) (F. H. Brt.) .....	Not shown	.....
00288¾	F	4	Rear Heel Board Brass Guides .....	23	.....
287	F	1	Front Heel Board .....	Not shown	.....
287¾	F	1	Front Heel Board Rim .....	Not shown	.....
S0288	F	13	Front Heel Board Rim Screws (¾-8) (F. H. Brt.) .....	Not shown	.....
840	F	1	Boiler Board .....	Not shown	.....
S00840	C	6	Boiler Board Screws (1¼-10 R. H. Brt.) .....	Not shown	.....
840½	F	1	Boiler Board Rim .....	Not shown	.....
S00840	C	7	Boiler Board Rim Screws (½-5 F. H. Brt.) ...	Not shown	.....
851	F	1	Door Pillar Brace R. H. ....	23	.....
851½	F	1	Door Pillar Brace L. H. ....	23	.....
S0243	C	8	Door Pillar Brace Screws (1-12 Ft. Hd. Anmid.)	Not shown	.....
801	F	1	Front Seat .....	Not shown	.....
0835	F	8	Front Seat Screws (2½-12 F. H. Brt.) .....	Not shown	.....
		2	Front Seat Pillar Bolts 2x¾ Mach. ....	Not shown	.....
		2	Front Seat Pillar Bolts (inside Plates Mach.)...	23	.....
0851¾	F	4	Front Seat Pillar Bolts (Inside Plate Screws 1-12) .....	Not shown	.....
830	F	1	Front Seat Cushion R. H. ....	Not shown	.....
831	F	1	Front Seat Cushion L. H. ....	Not shown	.....

# Canopy Tops

Stock No.	No. per Car.		Plate No.	Price.
001034 F	1	Canopy Top Center Catch (Small Window) .....	25	.....
001034½ F	1	Canopy Top Center Catch Strike (Small Win- dow) .....	25	.....
S00810 E	4	Canopy Top Center Catch Strike Screws ½-5 F. H. Br. ....	Not shown	.....
1035 F	1	Canopy Top Quarter Panel R. H. ....	Not shown	.....
1035½ F	1	Canopy Top Quarter Panel L. H. ....	Not shown	.....
001029 F	6	Canopy Top Quarter Panel Brackets .....	25	.....
1¼-1¼ Step	12	Canopy Top Quarter Panel Brackets Bolts .....	Not shown	.....
¼	12	Canopy Top Quarter Panel Brackets Nuts .....	Not shown	.....
1036 F	1	Canopy Top Quarter Window R. H. ....	Not shown	.....
1036½ F	1	Canopy Top Quarter Window L. H. ....	Not shown	.....
001037 F	8	Canopy Top Quarter Window Catches .....	25	.....
001037½ F	8	Canopy Top Quarter Window Catches Strikes ..	25	.....
¼-4				
F.H.Br.	32	Canopy Top Quarter Window Catches Strikes Screws .....	Not shown	.....
001038 F	2	Canopy Top Quarter Panel Standard Brackets Front .....	25	.....
001039 F	2	Canopy Top Quarter Panel Standard Brackets— Rear .....	25	.....
S001030 F	10	Canopy Top Quarter Panel Standard Brackets Bolts .....	25	.....
001039½ F	10	Canopy Top Quarter Panel Standard Brackets Washers .....	25	.....
1040 F	1	Canopy Top Quarter Rear Panel .....	Not shown	.....
001041 F	4	Canopy Top Quarter Rear Panel Corner Brackets .....	25	.....
S0243 C	10	Canopy Top Quarter Rear Panel Corner Bracket Screws 1x12 F. H. An. ....	Not shown	.....
1¼ 1¼ Step	4	Canopy Top Rear Panel Corner Bracket Bolts ..	Not shown	.....
¼	4	Canopy Top Rear Panel Corner Bracket Bolts Nuts .....	Not shown	.....
001020 F	3	Canopy Top Rear Panel Corner Frame Brackets ..	25	.....
1¼-1¼ Step	3	Canopy Top Rear Panel Frame Bracket Bolts ..	Not shown	.....
1½-¼ Step	2	Canopy Top Rear Panel Frame Bracket Bolts ..	Not shown	.....
1¼-¼ Step	2	Canopy Top Rear Panel Frame Bracket Bolts ..	Not shown	.....
¼ Step	7	Canopy Top Rear Panel Frame Bracket Bolt Nuts .....	Not shown	.....
1041 F	1	Canopy Top Rear Window .....	Not shown	.....
001042 F	2	Canopy Top Rear Window Sliding Hinges .....	25	.....
½-6				
F.H.Brass	12	Canopy Top Rear Window Sliding Hinges Screws .....	Not shown	.....
001030 E	2	Canopy Top Window Locks .....	25	.....
⅝-4				
F.H.Br.	8	Canopy Top Window Screws .....	Not shown	.....
001031 E	2	Canopy Top Window Clasps .....	25	.....

## Canopy Tops—Continued

58-7	F. H. Brass	4	Canopy Top Window Clasps Screws	Not shown
1041½	F	1	Canopy Top Rear Window—Center Small	Not shown
001033	F	2	Canopy Top Rear Window—Center—Hinges	Not shown
58-4	F. H. Brass	12	Canopy Top Rear Window—Center—Screws	Not shown
001034	F	1	Canopy Top Rear Window—Center—Catch	25
001034½	F	1	Canopy Top Rear Window—Center—Strike	25
800810	C	4	Canopy Top Rear Window—Center—Screws	
			¼-5 F. H. Brass	Not shown
1022	F	1	Canopy Top Front Window Glass—Upper	Not shown
1020½	F	1	Canopy Top Front Window Glass—Lower	Not shown
1044	F	2	Canopy Top Center Window Side Glasses	Not shown
1044½	F	1	Canopy Top Center Window Center Glasses	Not shown
1045	F	1	Canopy Top Side Quarter Glass R. H.	Not shown
1045½	F	1	Canopy Top Side Quarter Glass L. H.	Not shown
1046	F	2	Canopy Top Rear Window Side Glasses	Not shown
1046½	F	1	Canopy Top Rear Window Center Glasses	Not shown
1047	F	1	Canopy Top Center Window Curtain	Not shown
1047½	F	1	Canopy Top Center Window Curtain Hanger	
			R. H.	Not shown
1047¾	F	1	Canopy Top Center Window Curtain Hanger	
			L. H.	Not shown
1048½	F	2	Canopy Top Side Quarter Window Curtains	
			Hanger R. H.	Not shown
1048¾	F	2	Canopy Top Side Quarter Window Curtains	
			Hanger L. H.	Not shown
1049	F	1	Canopy Top Rear Window Curtain	Not shown
1047¾	F	1	Canopy Top Rear Window Curtain Hanger	
			R. H.	Not shown
1047¾	F	1	Canopy Top Rear Window Curtain Hanger	
			L. H.	Not shown

## Victoria Tops

1175	F	1	Victoria Top Front Bow	Not shown
1176	F	1	Victoria Top Center Bow	Not shown
1177	F	1	Victoria Top Rear Bow	Not shown
01178	F	1	Victoria Top Bow Eye Front R. H.	25
01179	F	2	Victoria Top Bow Eye Center R. H.	25
01180	F	1	Victoria Top Bow Eye Rear R. H.	25
01180½	F	4	Victoria Top Bow Eye Rivets	Not shown
01178½	F	1	Victoria Top Bow Eye Front L. H.	25
01179½	F	1	Victoria Top Bow Eye Center L. H.	25
01180¾	F	1	Victoria Top Bow Eye Rear L. H.	25
00676	F	1	Victoria Top Shifting Rail R. H.	25
00677	F	1	Victoria Top Shifting Rail L. H.	25
00678	F	1	Victoria Top Shifting Rail Cross Bar	25
01181	F	1	Victoria Top Joint R. H.—Upper	25
01182	F	1	Victoria Top Joint R. H.—Lower	25
01181½	F	1	Victoria Top Joint L. H.—Upper	25
01182½	F	1	Victoria Top Joint L. H.—Lower	25
01183	F	2	Victoria Top Joint Rivets	25

## Victoria Tops—Continued

01183½ F	2	Victoria Top Joint Rivet Washers .....	25	
01184 F	2	Victoria Top Joint Cap Nuts .....	25	
01185 F	2	Victoria Top Joint Prop Bumpers .....	Not shown	
00296 F	4	Victoria Top Shifting Rail Lock Nuts .....	24	
1187 F	1	Victoria Top Rear Curtain .....	Not shown	
001186 F	7	Victoria Top Rear Curtain Fasteners—Brewster .....	25	
1187½ F	2	Victoria Top Rear Curtain Straps .....	Not shown	
01184½ F	2	Victoria Top Joint Prop .....	25	
1184¾ F	2	Victoria Top Joint Prop Thimbles .....	25	
1190 F	1	Victoria Top Front Apron .....	Not shown	
1191 F	1	Victoria Top Dust Cover .....	Not shown	
1188 F	1	Victoria Top Rear Curtain Light .....	Not shown	